

Note:

- Not perfect match with TapTes Qi wireless charger box for Model S, you can use our Qi charger, but then can not close the console front cover like the 2017 Model S.
- There is a small gap if you close both front console cover and back console cover, however most cases back console cover is open as you may need to put some small stuff in, in this case no gap.
- Installation video visit : https://youtu.be/mSeh5v_Ijew
Or scan the QR code below :



- ① Insert main body, no need to insert two side leather baffle first



- ② Adjust main body to an appropriate position so power hole and USB interface can be easily used, note: for some Model S you may need to insert the center console main body as close to the car front as possible, push the rear main body down if it conflicts with the cup area (the center console rear side is soft which can be pushed)



- ③ Mounting side leather baffle gently



- ④ Installation of the grid



Contact us:

Add: Unit 3 27/F Ho King Comm Centre, Mongkok, KL, Hong Kong

Phone Number: +852 3050 6756

Email: sales@taptes.com