



Assembly instructions

1. Drill a hole of 8 mm (driller not included)
2. Place the dowel in the borehole
3. Turn the wall hook into the dowel

- Made out of concrete
- Handmade in Austria
- Usable up to 25 kg
- Weatherproof

AUSFLUG

THOMAS
POGANITSCH

HANDMADE IN VIENNA