

www.veroboard.com

INSTALLATION INSTRUCTIONS 4" Multi Application Recessed Downlight

IMPORTANT: Read all instructions before installing fixtures. Retain for future reference.

SAFETY: For your safety, this fixture must be wired in accordance to local electrical codes and ordinances. All work should be done by a qualified electrician.

WARNING: Make certain power is OFF from the electrical panel before starting installation or attempting any maintenance.

INCLUDED COMPONENTS

- 1 × SlimLED Multi fixture
- 2 × Butterfly clips with screws (sold seperately)
- 1 × Medium base adapter with quick connector (sold seperately)
- · 2 × M4 screws with silicone washer

SEMI-RECESSED-MOUNT INSTALLATION

- Cut the terminal ring at the end of the ground wire (yellow-green) on the back of the luminaire. Make the electrical connections. Connect the ground wires (yellow-green/green).
 Connect the neutral wires (white). Connect the live wires (black) [Fig. 1].
- Secure the luminaire to the junction box with provided M4 screws with silicone washer [Fig. 2].
- Install the selected trim ring by placing the metal side towards the luminaire. The magnets on the luminaire will secure the trim ring in place [Fig. 3].
- 4. Turn on the power for testing.

RECESSED HOUSING INSTALLATION

- Secure the butterfly clips to the luminaire with the two screws provided [Fig. 4].
- Secure the medium based adaptor into socket in recessed housing [Fig. 5].
- Insert the wires from the luminaire to the quick connector.
 Connect the live (black) wire to the marked slot of the quick connector [Fig. 6].
- 4. Connect the ground wire (yellow-green) by securing the terminal ring to the recessed housing using the provided self-tapping screw. Use 1/8" drill bit to drill the hole on the recessed housing for the self-tapping screw. (Hook up the light with the medium base adaptor by the quick connectors.) Squeeze spring clips and install the luminaire in recessed housing. Make sure the luminaire is centered in recessed housing [Fig. 7].
- Install the selected trim ring by placing the metal side towards the luminaire. The magnets on the luminaire will secure the trim ring in place [Fig. 8].
- 6. Turn on the power for testing















