

ARM
Motorsports



ARMMOTORSPORTS.COM

B58 F-SERIES



B58 INTAKE INSTALL



TURTLE
Expert Auto Mechanic



Our B58 Inlet is one of the best looking ones on the market, choose the plexiglass cover, and see the inner workings of the filter, without sucking in hot air. Oh, and there's some spooly boy noises too that come with it.

× × × ×

**30-60
MINUTE**

Install time

DIFFICULTY

EASY



TURTLE
Expert Auto Mechanic

PRO TIP

Allow the vehicle to cool down before doing this install

× × × ×

Tools Required

- Metric Driver Set
- Screw Driver

× × × ×




TURTLE
Expert Auto Mechanic



01

UNPLUG THE MAF SENSOR

- You will need to depress the tab, and pull the MAF plug out.




TURTLE
Expert Auto Mechanic






LOOSEN THE LOWER HOSE CLAMP

- 8mm Screws in red



02



TURTLE
Expert Auto Mechanic



03

REMOVE THE INTAKE

- Pull directly up on the entire airbox
- It is held on by the gromets below




TURTLE
Expert Auto Mechanic



04

**INSTALL SLIP JOINT WITH
PROVIDED CLAMP AND
TIGHTEN**



TURTLE
Expert Auto Mechanic





**INSTALL CLAMP ON 90
DEGREE ELBOW AND THEN
PLACE ON THE JOINT (DO
NOT TIGHTEN DOWN THE
CLAMP AS IT WILL MAKE IT
EASIER TO INSTALL THE REST
OF THE SYSTEM).**



TURTLE
Expert Auto Mechanic



6



**INSTALL INTAKE PIPE TO THE
ELBOW. (ALSO DO NOT
TIGHTEN THIS CLAMP)**



TURTLE
Expert Auto Mechanic





INSTALL THE LARGER WEATHER STRIPPING AROUND THE HEAT SHIELD HOLE



TURTLE
Expert Auto Mechanic



08

**INSTALL THE REST SMALLER WEATHER STRIPPING AROUND
BOTTOM PORTIONS OF THE BOX. (SPRAY ADHESIVE OR
HAIR SPRAY WILL HELP YOU TACK IT DOWN).**



TURTLE
Expert Auto Mechanic



9




**INSTALL THE HEATSHIELD.
(THIS PIECE IS A HUGE PAIN
TO INSTALL AND YOU WILL
HAVE TO ROTATE SOME PIECES
TO GET THE PIPE IN THE HOLE)**



TURTLE
Expert Auto Mechanic



10




**INSTALL THE MAFF USING THE
"2" 4MM ALLENS PROVIDED**



TURTLE
Expert Auto Mechanic



11




**ONCE ACHIEVED SLIP ON THE
FILTER.(THE BIGGEST CLAMP
IS FOR THE INTAKE).**



TURTLE
Expert Auto Mechanic





**INSTALL THE HEATSHIELD
COVER WITH THE "3" 4MM
ALLENS PROVIDED**



TURTLE
Expert Auto Mechanic





**GO BACK TO STEP 2 AND 3
AND TIGHTEN THE REST OF
THE CLAMPS.**



TURTLE
Expert Auto Mechanic





#GETARMED

ARMMOTORSPORTS.COM

CONGRATULATIONS!

Enjoy your B58 Intake

× × × × × × × ×



WAS THIS HELPFUL?

Email in to GETARMED@ARMMOTORSPORTS.COM for any additional help, please send photos of any fitment issues.



Save For Later

TURTLE
Expert Auto Mechanic

