



13000 Temple Ave. City of Industry, CA 91746

Tech line (626) 968-5147 Main line (800) 237-7560
www.dcsports.com

CAI5021
COLD AIR INTAKE INSTALLATION INSTRUCTIONS
2006-2009 HONDA S2000 2.2L

**!!! READ ALL INSTRUCTION THOROUGHLY BEFORE BEGINNING
INSTALLATION. FAILURE TO DO SO MAY RESULT IN COSTLY ENGINE
AND/OR SYSTEM DAMAGE!!!**

*****IF UNSURE ABOUT INTAKE SYSTEM INSTALLATION PLEASE HAVE A
REPUTABLE PERFORMANCE SHOP OR A LICENCED MECHANIC
INSTALL THIS SYSTEM*****

*****FOR YOUR SAFETY, ALLOW ENGINE TO COOL FOR AT LEAST AN
HOUR BEFORE BEGINNING INSTALLATION*****

*****PLEASE CHECK AND MAKE SURE ALL HARDWARE IS PRESENT
BEFORE INSTALLATION. PARTS LIST ON LAST PAGE*****

A.R.B INFORMATION
*****THIS DC SPORTS INTAKE ARE CARB EXEMPT
PER EO#D-370-13 FOR 06-07 S2000 ONLY*****

TOOLS REQUIRERD
Ratchet 10mm, and 11mm deep socket
Flat Screwdriver
12" Extension
Pliers
Cutting Tool

REMOVAL OF STOCK INTAKE AND INSTALLATION OF INTAKE SYSTEM

1. On the throttle body loosen clamp securing the factory intake tube.
2. Unhook all the wire harness and hoses attached to the factory intake tube.
3. Remove the air temp sensor from the factory intake tube.
4. Depress the clamp and remove the crankcase plenum from the OEM intake tube.
5. Unclip six metal tabs securing the factory air box top and remove top from vehicle.
6. Remove factory intake tube and filter from vehicle.
7. Locate and remove three 10mm bolts securing the lower section air box to the chassis.
8. Remove factory air box from vehicle.
9. Remove the crankcase breather hose from the valve cover and unclip the wire harness from the coolant/crankcase plenum.
10. **CAUTION: Please make sure engine is cool before working on these next few steps.**
11. Remove the coolant hose from the throttle body and also at the other end.
12. Remove the coolant/crankcase plenum "hard line" from vehicle.
13. Install provided 8mm hose in place of coolant hose that was just removed and reuse factory clamps.
14. Install provided 3.00" coupler and two clamps onto the throttle body, only tighten down the clamp on

- the throttle body side at this time.
15. Install provided 3.00" coupler with two clamps onto the primary tube, only tighten clamp on the tube side at this time.
 16. Carefully install the primary intake tube into the throttle body, do not tighten down the clamps at this time.
 17. Jack up the passenger side of the vehicle and support with jack stands. Remove passenger side front wheel.
 18. Remove passenger side fender liner by locating three plastic clips and five 10mm bolts.
 19. Install the secondary intake tube.
 20. Notice the welded bracket on the secondary pipe install the provided vibration mount between the bracket and the chassis.
 21. Secure bracket onto the vibration mount with provided washer and nylon nut.
 22. Install DC Sports air filter onto the bottom of the secondary intake pipe.
 23. Install provided 10mm vacuum hose onto the crankcase breather vent off the valve cover and the other end into the intake tube.
 24. Plug the air temp sensor into the grommet on the intake tube. Then zip tie the air temp wiring to the wire loom along the frame.
 25. Reinstall fender liner and splash guard.
 26. **NOTE: You will have to do minor trimming of the fender liner for clearance with the intake tube.**
 27. Installation is now complete check all work performed.

*****LIMITED 10 YEAR WARRANTY*****

DC Sports only warranty's intake systems due to poor workmanship. We do not cover normal wear and tear damages due to misuse or abuse. We do not warranty the finish of intake tubes.

Warranty covers the original owner of intake system by having proof of purchase. We have the right to void all warranty if you cannot provide the information needed by DC Sports. DC Sports does not cover any cost for installation or removal of products.

*****CAUTION*****

DC Sports does not assume any liability for damage caused by rain or floods causing the intake system for taking on water. We recommend that you remove the cold air intake system due to wet conditions.

*****WARRANTY CLAIMS*****

All warranty claims must be shipped prepaid by the customer to DC Sports. Warranty claims must have an RMA (Return Merchandise Authorization) number on the box or package will be refused and sent back to the shipper.

PARTS LIST

Quantity	Part Number	Part Description
1	DCCAP5021-1	CAI5021 PRIMARY INTAKE TUBE
1	DCCAP5021-2	CAI5021 SECONDARY INTAKE TUBE
2	DCCP300	3.00" STRAIGHT COUPLER
10"	DCHH8MM	8MM HEATER HOSE
13"	DCVH10MM	10MM VACUUM HOSE
1	DCCL300	3.00" CLAMP
3	DCCL325	3.25" CLAMP
1	DCRG58	5/8" RUBBER GROMMET
1	DCVM6MM	M6 M/M VIBRA MOUNT
1	DCFW1	FENDER WASHER
1	DCLNM6	M6 NYLON LOCK NUT
1	DCZT1	ZIP TIE

1	DCF300	3.00" DC Sports FILTER PACK
2	DCDECAL	DC Sports DECALS

THANK YOU FOR CHOOSING DC SPORTS