



DC Sports
13000 Temple Ave
City of Industry Ca, 91746
T. 626-937-6988
www.dcsports.com

CAI5529
COLD AIR INTAKE INSTALLATION INSTRUCTIONS
2003-2007 HONDA ACCORD V6 3.0L / 2004-2008 ACURA TL 3.2L

**!!! READ ALL INSTRUCTION THOROUGHLY BEFORE BEGINNING
INSTALLATION. FAILURE TO DO SO MAY RESULT IN COSTLY ENGINE
AND/OR SYSTEM DAMAGE!!!**

*****IF UNSURE ABOUT INTAKE SYSTEM INSTALLATION PLEASE HAVE A
REPUTABLE PERFORMANCE SHOP OR A LICENCED MECHANIC
INSTALL THIS SYSTEM*****

*****FOR YOUR SAFETY, ALLOW ENGINE TO COOL FOR AT LEAST AN
HOUR BEFORE BEGINNING INSTALLATION*****

*****PLEASE CHECK AND MAKE SURE ALL HARDWARE IS PRESENT
BEFORE INSTALLATION. PARTS LIST ON LAST PAGE*****

A.R.B INFORMATION
*****THIS DC SPORTS INTAKE ARE CARB EXEMPT
PER EO#D-370-15 FOR 03-05 HONDA ACCORD 3.0L AND 04-08 ACURA TL
3.2L ONLY*****

TOOLS REQUIRED

Pliers
Ratchet 8mm, 10mm, 11mm, Deep Socket
Phillips Screwdriver
Flat Screwdriver
6" Extension

REMOVAL OF STOCK INTAKE AND INSTALLATION OF INTAKE SYSTEM

1. Loosen clamp holding factory intake tube from the throttle body.
2. Loosen small clamp attaching the crankcase breather line to the OEM intake tube and remove.
3. Remove harness wire from the OEM intake tube.
4. Remove OEM intake tube by sliding away from the throttle body, and also do the same for the intake tube from the factory air box.
5. Locate and unscrew the two 10mm bolts holding the factory air box to the chassis.
6. Lifting up the factory air box will expose a wire harness attached on the air box. Unclip the three clips

- holding the harness on the air box
7. Loosen the battery tie down so that the car battery can be repositioned for clearance for factory air box removal.
 8. Remove factory air box from vehicle and place car battery back into its original location. Then tighten down the battery tie down.
 9. Remove factory front bumper by removing the ten clips on the top of the grille, two screws and six plastic clips from the sides of the bumper, and two 10mm bolts on the bottom of the bumper.
 10. After front bumper is removed locate the two 10mm bolts holding the resonator box attaching it to the chassis.
 11. Remove factory resonator box.
 12. Pull to unclip plastic tab holding headlamp cover and remove.
 13. Locate 10mm bolt holding lower section of the factory intake tube to the chassis and remove bolt and lower factory intake tube.
 14. **CAUTION: MAKE SURE ENGINE IS COLD BEFORE STARTING THESE NEXT STEPS OF INSTALLATION.**
 15. Remove coolant line and crankcase plenum.
 16. Replace the coolant line with the 8mm heater hose provided.
 17. Install 12.7mm crankcase breather line onto the valve cover.
 18. Unclip the A/C line from the crankcase plenum.
 19. Install reducer coupler provided with two clamps onto the throttle body. But only tighten down the clamp on the throttle body side at this time.
 20. Slide intake tube onto the reducer on the throttle body, and align the bracket on the tube where the 10mm bolt was removed to take out the factory resonator box and replace with vibration mount and attach the washer and nylon nut provided.
 21. Tighten the second clamp on the throttle body towards the intake tube.
 22. Attach the other end of the crankcase line to the vent nipple on the intake pipe.
 23. Install the air filter to the intake pipe.
 24. Reinstall the factory front bumper in reverse order as in step 9.
 25. Install is now complete. Please double check all clamps and bolts.

*****LIMITED 3 YEAR WARRANTY*****

DC Sports only warranty's intake systems due to poor workmanship. We do not cover normal wear and tear damages due to misuse or abuse. We do not warranty the finish of intake tubes.

**Warranty covers the original owner of intake system by having proof of purchase.
We have the right to void all warranty if you cannot provide the information needed by DC Sports.
DC Sports does not cover any cost for installation or removal of products.**

*****CAUTION*****

DC Sports does not assume any liability for damage caused by rain or floods causing the intake system for taking on water. We recommend that you remove the cold air intake system due to wet conditions.

*****WARRANTY CLAIMS*****

**All warranty claims must be shipped prepaid by the customer to DC Sports.
Warranty claims must have an RMA (Return Merchandise Authorization) number on the box or package will be refused and sent back to the shipper.**

PARTS LIST

Quantity	Part Number	Part Description
1	DCCAP6514	CAI5529 INTAKE TUBE
13"	DCHH8MM	8MM HEATER HOSE
14"	DCVH10MM	10MM VACUUM HOSE
1	DCCP275-300	2.75/3.00" COUPLER REDUCER
1	DCCL275	2.75" CLAMPS
1	DCCL300	3.00" CLAMPS
1	DCVM6MM	M6 M/M VIBRA MOUNT
1	DCF300	3.00" DC SPORTS FILTER PACK
1	TMTAG-CARBEO15	D-370-15 carb sticker
2	DCDECAL	DC SPORTS DECALS

THANK YOU FOR CHOOSING DC SPORTS