



13000 Temple Ave. City of Industry, CA 91746

Tech line (626) 968-5147 Main line (800) 237-7560  
www.dcsports.com

**CAI5604**  
**COLD AIR INTAKE INSTALLATION INSTRUCTIONS**  
**1999-2000 HONDA CIVIC SI 1.6L**

**!!! READ ALL INSTRUCTION THOROUGHLY BEFORE BEGINNING  
INSTALLATION. FAILURE TO DO SO MAY RESULT IN COSTLY ENGINE  
AND/OR SYSTEM DAMAGE!!!**

**\*\*\*IF UNSURE ABOUT INTAKE SYSTEM INSTALLATION PLEASE HAVE A  
REPUTABLE PERFORMANCE SHOP OR A LICENCED MECHANIC  
INSTALL THIS SYSTEM\*\*\***

**\*\*\*FOR YOUR SAFETY, ALLOW ENGINE TO COOL FOR AT LEAST AN  
HOUR BEFORE BEGINNING INSTALLATION\*\*\***

**\*\*\*PLEASE CHECK AND MAKE SURE ALL HARDWARE IS PRESENT  
BEFORE INSTALLATION. PARTS LIST ON LAST PAGE\*\*\***

**A.R.B INFORMATION**

**\*\*\*THIS DC SPORTS INTAKE ARE CARB EXEMPT  
PER EO#D-370-13 FOR 99-00 HONDA CIVIC SI 1.6L ONLY\*\*\***

**TOOLS REQUIRERD**

**Ratchet 10mm, and 11mm, 12mm deep socket  
Flat Screwdriver  
Phillips Screwdriver  
Pliers  
6" Extension**

**REMOVAL OF STOCK INTAKE AND INSTALLATION OF INTAKE SYSTEM**

1. Loosen and remove the strut tower bar by removing the four 12mm nuts.
2. Loosen the clamp securing the factory intake tube to the throttle body.
3. On the factory intake tube unplug the air temp sensor and the crankcase breather hose.
4. Remove the vacuum hose from the valve cover by depressing the clamp.
5. Disconnect the coolant plenum from the throttle body and motor. Remove the coolant plenum from the vehicle.
6. With provided 8mm heater hose replace coolant hose that was just removed.
7. Remove front bumper by locating five plastic clips securing the upper section of the bumper cover.
8. Locate and remove two phillips screws securing the bumper to the fender on both fender wells
9. Underneath the bumper in the center locate and remove two 10mm bolts securing the bumper to the chassis.
10. Remove front bumper.
11. Remove the factory air box by removing the two 10mm bolts securing the air box to the chassis.
12. Remove the resonator box by locating three 10mm bolts that secure the resonator box to the chassis.
13. Install provided 2.75" coupler and two clamps onto the throttle body but only tighten the clamp towards

- the throttle body at this time
14. Loosely install the DC Sports intake tube into the throttle body.
  15. Notice the welded bracket on the intake tube. Install provided vibration mount between the bracket and the chassis.
  16. Align the bracket on top of the vibration mount and use provided washer and nut to secure the intake tube.
  17. Tighten remaining clamp on the throttle body and make sure the pipe is free from any obstructions
  18. Install the 10mm vacuum hose onto the intake tube nipple and the other end into the valve cover.
  19. Plug air temperature sensor into the grommet on the DC sports intake tube.
  20. Install the DC Sports air filter into the intake tube.
  21. Reinstall the bumper cover on reverse order it was removed.
  22. Reinstall the strut bar.
  23. Installation is now complete check all work performed.

**\*\*\*LIMITED 10 YEAR WARRANTY\*\*\***

**DC Sports only warranty's intake systems due to poor workmanship. We do not cover normal wear and tear damages due to misuse or abuse. We do not warranty the finish of intake tubes.**

**Warranty covers the original owner of intake system by having proof of purchase.  
We have the right to void all warranty if you cannot provide the information needed by DC Sports.  
DC Sports does not cover any cost for installation or removal of products.**

**\*\*\*CAUTION\*\*\***

**DC Sports does not assume any liability for damage caused by rain or floods causing the intake system for taking on water. We recommend that you remove the cold air intake system due to wet conditions.**

**\*\*\*WARRANTY CLAIMS\*\*\***

**All warranty claims must be shipped prepaid by the customer to DC Sports.  
Warranty claims must have an RMA (Return Merchandise Authorization) number on the box or package will be refused and sent back to the shipper.**

**PARTS LIST**

Quantity	Part Number	Part Description
1	DCCAP5604	CAI5604 INTAKE TUBE
1	DCCP275	2.75" STRAIGHT COUPLER
10"	DCHH8MM	8MM HEATER HOSE
13"	DCVH10MM	10MM VACUUM HOSE
2	DCCL275	2.75" CLAMP
1	DCRG58	5/8" RUBBER GROMMET
1	DCVM6MM	M6 M/M VIBRA MOUNT
1	DCF300	3.00" DC SPORTS FILTER PACK
2	DCDECAL	DC SPORTS DECAL

**THANK YOU FOR CHOOSING DC SPORTS**