



13000 Temple Ave. City of Industry, CA 91746

Tech line (626) 968-5147 Main line (800) 237-7560
www.dcsports.com

CSB1101 STRUT TOWER BAR INSTALLATION INSTRUCTIONS

1998-2004 DODGE NEON (ALL) FRONT STRUT BAR

**READ ALL INSTRUCTIONS THROUGH COMPLETELY BEFORE BEGINNING
INSTALLATION.**

**IF YOU ARE NOT COMFORTABLE AND/OR FAMILIAR WITH THESE INSTRUCTIONS, PLEASE
REFER THIS INSTALLATION TO A QUALIFIED PROFESSIONAL.**

1. Remove the two nuts that secure the strut to the strut tower. These will be the two nuts closest to the engine and there will be two on each side.
2. Carefully slide the DC Sports strut bar over the studs that remain. You may need to remove the rubber weather stripping for clearance. If it still seems to be tight, remove the third nut from each side and jack up the front of the car until the strut studs drop down just enough for the strut bar to clear.
3. Once the bar is in place, replace all nuts and tighten to 19 ft.lb.

PARTS LIST

Quantity	Part Number	Part Description
1	CSB1101	Carbon steel strut tower bar
2	DCS1008	DC Sports decals

THANK YOU FOR CHOOSING DC SPORTS