



13000 Temple Ave. City of Industry, CA 91746

Tech line (626) 968-5147 Main line (800) 237-7560  
www.dcsports.com

## **CSB1102 SHOCK TOWER BAR INSTALLATION INSTRUCTIONS**

**2005-Current Chrysler 300C , Dodge Magnum, Dodge Charger,**  
**2005-Current Chrysler 300C SRT-8 , Dodge Magnum SRT-8**

**READ INSTRUCTIONS THROUGH COMPLETELY BEFORE BEGINNING  
INSTALLATION. FAILURE TO DO SO MAY RESULT IN COSTLY ENGINE  
DAMAGE!!!**

**FOR YOUR SAFETY ALLOW ENGINE TO COOL FOR AT LEAST AN HOUR  
BEFORE BEGINNING INSTALLATION.**

**IF YOU ARE NOT COMFORTABLE AND/OR FAMILIAR WITH THESE INSTRUCTIONS,  
PLEASE REFER THIS INSTALLATION TO A QUALIFIED PROFESSIONAL.**

### **UNDER THE HOOD:**

1. Remove the shock tower covers, and the engine cover if equipped.
2. Remove three (3) 10mm nuts from the left side shock tower and three (3) 10mm nuts from the right side shock tower using a 13mm socket. These nuts will be reused later.
3. using a jack, lift the front of the car until the weight of the car is not supported by the springs.
4. Install the DC Sports Strut Tower Bar over the shock tower studs (the shock tower top may need to be adjusted to properly fit the length of the shock tower bar. This will not effect the vehicle alignment.) Loosely reinstall the original shock tower nuts. Tighten the shock tower nuts (Torque: 27 N·m (20 ft.lbs.) torque.).
5. **CHECK ALL OF YOUR WORK.**

### **PARTS LIST**

<b>Quantity</b>	<b>Part Number</b>	<b>Part Description</b>
1	CSB1102	DC Sports front strut tower bar
2	DCS1008	DC Sports decals

**THANK YOU FOR CHOOSING DC SPORTS**