



13000 Temple Ave. City of Industry, CA 91746

Tech line (626) 968-5147 Main line (800) 237-7560  
www.dcsports.com

## **CSB1501 STRUT TOWER BAR INSTALLATION INSTRUCTIONS**

### **2003-2007 Hyundai Tiburon V6**

**READ INSTRUCTIONS THROUGH COMPLETELY BEFORE BEGINNING  
INSTALLATION. FAILURE TO DO SO MAY RESULT IN COSTLY ENGINE  
DAMAGE!!!**

**FOR YOUR SAFETY ALLOW ENGINE TO COOL FOR AT LEAST AN HOUR  
BEFORE BEGINNING INSTALLATION.**

**IF YOU ARE NOT COMFORTABLE AND/OR FAMILIAR WITH THESE INSTRUCTIONS,  
PLEASE REFER THIS INSTALLATION TO A QUALIFIED PROFESSIONAL.**

#### **UNDER THE HOOD:**

1. Remove the six (6) 10mm nuts from both shock towers (three (3) per side) using a 14mm socket. These nuts will be reused later.
2. Install the DC Sports Strut Tower Bar over the shock tower studs and loosely reinstall the original shock tower nuts.
3. Check for proper clearance from all other parts of the vehicle. If anything is touching or close please provide clearance accordingly.
4. Torque down the two nuts closest to the center of the car first, the 2 front most nuts second, and the 2 rear most nuts last (Torque: 4.5 kg-m - 6.0 kg-m, 33 lb-ft - 43 lb-ft).
5. **CHECK ALL OF YOUR WORK.**

#### **PARTS LIST**

<b>Quantity</b>	<b>Part Number</b>	<b>Part Description</b>
1	CSB1501	DC Sports front strut tower bar
2	DCS1008	DC Sports decals

**THANK YOU FOR CHOOSING DC SPORTS**