



13000 Temple Ave. City of Industry, CA 91746

Tech line (626) 968-5147 Main line (800) 237-7560
www.dcsports.com

CSB2101 Rear Strut Tower Bar INSTALLATION INSTRUCTIONS

2003 Dodge Neon SRT-4

READ INSTRUCTIONS THROUGH COMPLETELY BEFORE BEGINNING INSTALLATION.

**IF YOU ARE NOT COMFORTABLE AND/OR FAMILIAR WITH THESE INSTRUCTIONS, PLEASE
REFER THIS INSTALLATION TO A QUALIFIED PROFESSIONAL.**

1. Locate rear shock tower studs by removing the rear trunk panels (Picture A).
NOTE: The rear trunk panels can be completely removed to accommodate for the rear strut tower bar or holes can be cut out to allow the rear trunk panels to be re-installed with the rear strut tower bar in place.
2. With the car set on the ground, remove the two (2) 8mm shock nuts (These are the nuts closest to the middle of the car) on each side.
3. Install the right rear strut tower bracket (they are marked on the bottom side of the bracket) by sliding the bracket over the shock studs ensuring that the bracket does not interfere with any parts of the vehicle. Re-install the two (2) original 8mm nuts. But do not tighten.
4. Install the left rear strut tower bracket by sliding the bracket over the shock studs also ensuring that the bracket does not interfere with any parts of the vehicle. Re-install the two (2) original 8mm nuts and tighten (Torque: 19 lb-ft).
5. Back to the right side shock tower, tighten the two (2) 8mm nuts (Torque: 19 lb-ft).
6. **RE-CHECK ALL YOUR WORK.**



Picture A

PARTS LIST

Quantity	Part Number	Part Description
1	CSB2101	Rear upper strut tower bar
2	DCS1008	DC Sports decals

THANK YOU FOR CHOOSING DC SPORTS