

Tech line (626) 968-5147 Main line (800) 237-7560 www.dcsports.com

CSB3022

STRUT TOWER BAR INSTALLATION INSTRUCTIONS

2003-Current 4 Cyl. / 6 Cyl. Honda Accord Excluding 2 Door V6 6 Speed MT & Hybrid Models

READ INSTRUCTIONS THROUGH COMPLETELY BEFORE BEGINNING INSTALLATION. FAILURE TO DO SO MAY RESULT IN COSTLY ENGINE DAMAGE!!!

FOR YOUR SAFETY ALLOW ENGINE TO COOL FOR AT LEAST AN HOUR BEFORE BEGINNING INSTALLATION.

IF YOU ARE NOT COMFORTABLE AND/OR FAMILIAR WITH THESE INSTRUCTIONS, PLEASE REFER THIS INSTALLATION TO A QUALIFIED PROFESSIONAL.

UNDER THE HOOD:

- 1. Remove three (3) 10mm nuts from the left side shock tower and three (3) 10mm nuts from the right side shock tower. These nuts will be reused later.
- 2. Install the DC Sports Strut Tower Bar over the shock tower studs as shown below.



- 3. Reinstall the original 10mm nuts and tighten (Torque: 4.5 kg-m 6.0 kg-m, 33 lb-ft 43 lb-ft).
- 4. CHECK ALL OF YOUR WORK.

PARTS LIST

Quantity	Part Number	Part Description
1	CSB3022	DC Sports front strut tower bar
2	DCS1008	DC Sports decals

THANK YOU FOR CHOOSING DC SPORTS