



13000 Temple Ave. City of Industry, CA 91746

Tech line (626) 968-5147 Main line (800) 237-7560  
www.dcsports.com

## **CSB4505 Strut Tower Bar Installation Instructions**

### **2013-2017 Hyundai Veloster**

**READ ALL INSTRUCTIONS THROUGH COMPLETELY BEFORE BEGINNING  
INSTALLATION.**

**IF YOU ARE NOT COMFORTABLE AND/OR FAMILIAR WITH THESE INSTRUCTIONS, PLEASE  
REFER THIS INSTALLATION TO A QUALIFIED PROFESSIONAL.**

1. Remove caps from windshield wiper arms, then remove the 14mm nuts underneath. Note the orientation of the wiper arms, mark them or take a picture if necessary to insure they go back on the same way. Carefully wiggle loose the wiper arms and remove them.
2. Locate the four (4) pins holding the cowl down. Gently push down on the center of the pins to release them.
3. Locate windshield wiper fluid hose and remove. This will be on the left side of the engine bay near the passenger fender.
4. Carefully remove cowl.
5. With the car on the ground, loosen the three (3) 14 mm nuts on each strut tower. Only two (2) from each side will be completely removed.
6. Loosely reinstall the original shock tower nuts. Tighten the shock tower nuts (Torque: 27 N-m (20 ft.lbs.) torque).
7. Re-install cowl, wiper fluid hose, and wiper arms.
8. Ensure that the DC Sports Carbon Steel Strut Tower Bar does not interfere with any parts of the vehicle.
9. **RECHECK ALL YOUR WORK.**

### **PARTS LIST**

<b>Quantity</b>	<b>Part Number</b>	<b>Part Description</b>
1	CSB1004	Carbon steel strut bar
2	DCS1008	DC Sports decals

**THANK YOU FOR CHOOSING DC SPORTS**