



City of Industry, CA 91746

T. 626-937-6988

CSB5532
Strut Tower Bar Installation Instructions
2016-2018 Honda Civic (ex Type R)

READ INSTRUCTIONS THROUGH COMPLETELY BEFORE BEGINNING INSTALLATION. FAILURE TO DO SO MAY RESULT IN COSTLY ENGINE DAMAGE!!!

FOR YOUR SAFETY ALLOW ENGINE TO COOL FOR AT LEAST AN HOUR BEFORE BEGINNING INSTALLATION.

IF YOU ARE NOT COMFORTABLE AND/OR FAMILIAR WITH THESE INSTRUCTIONS, PLEASE REFER THIS INSTALLATION TO A QUALIFIED PROFESSIONAL.

1. With the car set on the ground, remove three (3) 14mm nuts on the left side shock tower and three (3) 14mm nuts on the right-side shock tower.
2. Remove two (2) oem strut plates. (will not be re used)
3. Install the DC Sports Carbon Steel Strut Tower Bar over the shock tower studs on each side.
4. Install three (3) provided m10 nuts on the left side shock tower (Do not tighten) and three (3) M10 nuts on the right-side shock tower (Do not tighten).
5. Tighten all six (6) 14mm nuts (Torque: 4.4 kg-m, 32 lb-ft).
6. Ensure that the DC Sports Carbon Steel Strut Tower Bar does not interfere with any parts of the vehicle.
7. **RECHECK ALL YOUR WORK.**

Quantity	Part number	Part Description
1	CSB5532	CS-1 Carbon Strut bar
6	RHNA-M10x1.25	M10x1.25 flange nut
1	CSB5532BP	Strut bar protector
2	DCS1008	DC Sports Decals

