



**DC Sports**  
13000 Temple Ave  
City of Industry Ca, 91746  
T. 626-937-6988  
[www.dcsports.com](http://www.dcsports.com)

---

**NMS4201**

**EXHAUST SYSTEM INSTALLATION INSTRUCTIONS**  
**03-08 350Z/G35; 09-21 370Z; 09-15 G37; 14-16 Q60**

**!!! READ ALL INSTRUCTION THOROUGHLY BEFORE BEGINNING INSTALLATION. FAILURE TO DO SO MAY RESULT IN COSTLY ENGINE AND/OR SYSTEM DAMAGE!!!**

**\*\*\*IF UNSURE ABOUT SYSTEM INSTALLATION PLEASE HAVE A REPUTABLE PERFORMANCE SHOP OR A LICENCED MECHANIC INSTALL THIS SYSTEM\*\*\***

**\*\*\*FOR YOUR SAFETY, ALLOW ENGINE TO COOL FOR AT LEAST AN HOUR BEFORE BEGINNING INSTALLATION\*\*\***

**\*\*\*PLEASE CHECK AND MAKE SURE ALL HARDWARE IS PRESENT BEFORE INSTALLATION. PARTS LIST ON LAST PAGE\*\*\***

**TOOLS REQUIRED**

3/8 Socket Wrench  
3/8 6" extension  
14mm Socket  
10 mm Socket  
Flathead Screwdriver

**REMOVAL OF STOCK EXHAUST AND INSTALLATION OF EXHAUST SYSTEM**

1. Place car on even ground and securely place 4 jack stands under it.
2. Remove six (6) 10 nuts from OEM y pipe. Remove OEM y pipe.  
**STEP 3 ONLY APPLIES TO 03-08 350z/G35. If installing on G37, 370Z or Q60 please skip this step.**
3. Using 10mm socket and flathead screwdriver, remove both lower panels.
4. Install RM-CB60 Gaskets over OEM catalytic converter studs. (if studs are broken, they can be punched out and replaced with our hardware)
5. Install DC Sports Y Pipe, beginning with the passenger side flange and working the pipe towards the driver side flange. Do not tighten hardware yet.
6. Install RM-CB67 gasket onto rear of y pipe and mate to your exhaust using our hardware.
7. Make sure all nuts & bolts are tight and no parts of exhaust touches the body of car, heat shields or fuel tank.
8. Double check all your work.

**\*\*Before starting up, be sure to remove any grease, oil and fingerprints from the tubes. If the exhaust is run with these contaminants a permanent stain will form when the system becomes hot. To prevent this from happening, DC Sports suggests wiping the exhaust system down with a solution of mild detergent and water after installation. Any contaminants left on the exhaust tubes such as grease, oil, and/or fingerprints will result in PERMANENT staining. \*\***

**\*\*\*LIMITED 1 YEAR WARRANTY\*\*\***

**DC Sports only warranty's intake systems due to poor workmanship. We do not cover normal wear and tear damages due to misuse or abuse.**

**Warranty covers the original owner of intake system by having proof of purchase.  
We have the right to void all warranty if you cannot provide the information needed by DC Sports.  
DC Sports does not cover any cost for installation or removal of products.**

**\*\*\*WARRANTY CLAIMS\*\*\***

**All warranty claims must be shipped prepaid by the customer to DC Sports.  
Warranty claims must have an RMA (Return Merchandise Authorization) number on the box or package will be refused and sent back to the shipper.**

**PARTS LIST**

<b>Quantity</b>	<b>Part number</b>	<b>Part Description</b>
<b>1</b>	<i>NMS4201</i>	<i>NMS4201 Y pipe</i>
<b>2</b>	<i>RM-CB60</i>	<i>2.5" 2 Bolt High temp Gasket</i>
<b>1</b>	<i>TM-CB67</i>	<i>3' 2 Bolt High Temp Gasket</i>
<b>6</b>	<i>RHBA-M10x1.25x25</i>	<i>M10x1.25x25mm Long Bolt</i>
<b>6</b>	<i>RHNA-M10x1.25x25</i>	<i>M10x1.25x Nut</i>
<b>1</b>	<i>DCDECAL</i>	<i>DC Sports Decal (two pieces)</i>

**THANK YOU FOR CHOOSING DC SPORTS**