



DC Sports

13000 Temple Ave
City of Industry Ca, 91746
T. 626-937-6988

www.dcsports.com

SRI4301 SHORT RAM INTAKE INSTALLATION INSTRUCTIONS 2002-2007 SUBARU IMPREZA WRX 2.0L

**!!! READ ALL INSTRUCTION THOROUGHLY BEFORE BEGINNING
INSTALLATION. FAILURE TO DO SO MAY RESULT IN COSTLY ENGINE AND/OR
SYSTEM DAMAGE!!!**

*****IF UNSURE ABOUT INTAKE SYSTEM INSTALLATION PLEASE HAVE A
REPUTABLE PERFORMANCE SHOP OR A LICENCED MECHANIC INSTALL THIS
SYSTEM*****

*****FOR YOUR SAFETY, ALLOW ENGINE TO COOL FOR AT LEAST AN HOUR
BEFORE BEGINNING INSTALLATION*****

*****PLEASE CHECK AND MAKE SURE ALL HARDWARE IS PRESENT BEFORE
INSTALLATION. PARTS LIST ON LAST PAGE*****

A.R.B INFORMATION

*****THIS DC SPORTS INTAKE ARE CARB EXEMPT
PER EO#D-370-13 FOR 2002-2007 ONLY*****

TOOLS REQUIRERD

**Ratchet 10mm, and 11mm, and 12mm deep socket
Phillips Screwdriver
Flathead Screwdriver
12" Extension**

REMOVAL OF STOCK INTAKE AND INSTALLATION OF INTAKE SYSTEM

1. Locate and remove two 10mm bolts securing the air inlet to the radiator.
2. Loosen the two clamps securing the factory intake tube.
3. Unclip the vacuum hose and the cruise control cable from the factory intake.
4. Unplug the harness from the mass air flow sensor.
5. Locate and unclip the two clips securing the upper section of the air box.
6. Remove the upper section air box from the vehicle.
7. Locate and remove two 10mm bolts securing the air box to the chassis.
8. Remove the lower section air box from the vehicle.
9. Remove the factory intake tube from the vehicle.

10. Loosely install provided 2.75" coupler with two clamps onto the throttle body.
11. Remove the mass air flow sensor from the factory air box.
12. Install the mass air flow sensor onto the DC Sports intake tube with provided machine screws.
13. Loosely install the DC sports intake tube into the throttle body coupler.
14. Notice the welded bracket on the intake tube.
15. Remove the 10mm bolt underneath the welded bracket securing the power steering hard line.
16. Replace 10mm bolt with provided vibration mount and align bracket on top.
17. Tighten the two clamps securing the intake tube.
18. Secure the intake tube bracket to the vibration mount with provided washer and nut.
19. Plug in the harness to the mass air flow sensor.
20. Install the filter onto the intake pipe.
21. Installation is now complete check all work performed.

*****LIMITED 3 YEAR WARRANTY*****

DC Sports only warranty's intake systems due to poor workmanship. We do not cover normal wear and tear damages due to misuse or abuse. We do not warranty the finish of intake tubes.

**Warranty covers the original owner of intake system by having proof of purchase.
We have the right to void all warranty if you cannot provide the information needed by DC Sports.
DC Sports does not cover any cost for installation or removal of products.**

*****CAUTION*****

DC Sports does not assume any liability for damage caused by rain or floods causing the intake system for taking on water. We recommend that you remove the cold air intake system due to wet conditions.

*****WARRANTY CLAIMS*****

**All warranty claims must be shipped prepaid by the customer to DC Sports.
Warranty claims must have an RMA (Return Merchandise Authorization) number on the box or package
will be refused and sent back to the shipper.**

PARTS LIST

Quantity	Part Number	Part Description
1	DCSRP4301	SRI4301 INTAKE TUBE
1	DCCP275	2.75" STRAIGHT COUPLER
2	DCCL275	2.75" CLAMP
1	DCVM6MM	M6 M/M VIBRA MOUNT
2	DCPS8	8MM PHILLIPS MACHINE SCREW
1	DC-RAF300	3.00" DC Sports FILTER PACK
1	TMTAG-CARBE013	D-370-13 carb sticker
2	DCDECAL	DC Sports DECALS