



DC Sports
13000 Temple Ave
City of Industry Ca, 91746
T. 626-937-6988
www.dcsports.com

SRI5010
SHORT RAM INTAKE INSTALLATION INSTRUCTIONS
2002-2004 HONDA CR-V LX, EX, SE 2.4L
NOTE: WILL NOT FIT DRIVE BY WIRE

**!!! READ ALL INSTRUCTION THOROUGHLY BEFORE BEGINNING
INSTALLATION. FAILURE TO DO SO MAY RESULT IN COSTLY ENGINE
AND/OR SYSTEM DAMAGE!!!**

*****IF UNSURE ABOUT INTAKE SYSTEM INSTALLATION PLEASE HAVE A
REPUTABLE PERFORMANCE SHOP OR A LICENCED MECHANIC
INSTALL THIS SYSTEM*****

*****FOR YOUR SAFETY, ALLOW ENGINE TO COOL FOR AT LEAST AN
HOUR BEFORE BEGINNING INSTALLATION*****

*****PLEASE CHECK AND MAKE SURE ALL HARDWARE IS PRESENT
BEFORE INSTALLATION. PARTS LIST ON LAST PAGE*****

A.R.B INFORMATION
*****THIS DC SPORTS INTAKE ARE CARB EXEMPT
PER EO#D-370-13 FOR 2002-2004 ONLY*****

TOOLS REQUIRED
Ratchet 8mm, 10mm, and 11mm deep socket
Flat Screwdriver
Pliers
6" Extension

REMOVAL OF STOCK INTAKE AND INSTALLATION OF INTAKE SYSTEM

1. On the factory intake tube unclip the wire harness attached to the tube.
2. On the factory intake tube loosen the clamps on both ends.
3. On the factory intake tube locate and remove the air temperature sensor by pulling gently.
4. On the factory intake tube remove the OEM vacuum hose.
5. On the factory air box notice crankcase breather hose from the valve cover to the air box. Remove the hose closest to the air box.
6. On the factory air box locate two 10mm bolts and one 10mm nut securing the air box to engine and remove nut and bolts.
7. Remove factory air box from vehicle.
8. Remove factory intake tube from vehicle.
9. Remove factory vacuum hose from the engine.
10. On the throttle body install provided 2.75"/3.00" reducer coupler with two hose clamps but only tighten down the clamp on the throttle body side as of now.

11. Install the provided vibration mount onto the factory air box mount.
12. Install provided 15.9mm vacuum hose into the crankcase breather hose that was removed in step #5.
13. Install provided 8mm vacuum hose in place of the hose that was removed in step #9 and secure with factory clamp.
14. Install the DC Sports intake tube and align the welded bracket to the vibration mount.
15. With provided washer and nut secure the DC Sports intake tube to the vibration mount.
16. Tighten the remaining clamp on the throttle body at the intake side.
17. Plug the air temperature sensor into the rubber grommet on the intake tube.
18. Install both 15.9mm crankcase breather and 8mm vacuum hose into the intake tube.
19. Install the DC Sports air filter onto the intake tube.
20. Installation is now complete check all work performed.

*****LIMITED 3 YEAR WARRANTY*****

DC Sports only warranty's intake systems due to poor workmanship. We do not cover normal wear and tear damages due to misuse or abuse. We do not warranty the finish of intake tubes.

Warranty covers the original owner of intake system by having proof of purchase. We have the right to void all warranty if you cannot provide the information needed by DC Sports. DC Sports does not cover any cost for installation or removal of products.

*****CAUTION*****

DC Sports does not assume any liability for damage caused by rain or floods causing the intake system for taking on water. We recommend that you remove the cold air intake system due to wet conditions.

*****WARRANTY CLAIMS*****

All warranty claims must be shipped prepaid by the customer to DC Sports. Warranty claims must have an RMA (Return Merchandise Authorization) number on the box or package will be refused and sent back to the shipper.

PARTS LIST

Quantity	Part Number	Part Description
1	DCSRP1918	SRI1918 INTAKE TUBE
1	DCCP275-300	2.75"/3.00" COUPLER REDUCER
7"	DCVH8MM	8MM VACUUM HOSE
3.75"	DCVH159MM	15.9MM VACUUM HOSE
1	DCCL300	3.00" CLAMP
1	DCCL275	2.75" CLAMP
1	DCVM6MM	M6 M/M VIBRA MOUNT
1	DCRG58	5/8" RUBBER GROMMET
1	DCF300	3.00" DC SPORTS FILTER PACK
1	TMTAG-CARBEO13	D-370-13 carb sticker
2	DCDECAL	DC SPORTS DECAL

THANK YOU FOR CHOOSING DC SPORTS