



DC Sports
13000 Temple Ave
City of Industry Ca, 91746
T. 626-937-6988
www.dcsports.com

SRI5516
SHORT RAM INTAKE INSTALLATION INSTRUCTIONS
1992-1995 HONDA CIVIC DX, LX, EX, SI 1.6L

**!!! READ ALL INSTRUCTION THOROUGHLY BEFORE BEGINNING
INSTALLATION. FAILURE TO DO SO MAY RESULT IN COSTLY ENGINE
AND/OR SYSTEM DAMAGE!!!**

*****IF UNSURE ABOUT INTAKE SYSTEM INSTALLATION PLEASE HAVE A
REPUTABLE PERFORMANCE SHOP OR A LICENCED MECHANIC
INSTALL THIS SYSTEM*****

*****FOR YOUR SAFETY, ALLOW ENGINE TO COOL FOR AT LEAST AN
HOUR BEFORE BEGINNING INSTALLATION*****

*****PLEASE CHECK AND MAKE SURE ALL HARDWARE IS PRESENT
BEFORE INSTALLATION. PARTS LIST ON LAST PAGE*****

A.R.B INFORMATION

*****THIS DC SPORTS INTAKE ARE CARB EXEMPT
PER EO#D-370-13 FOR 92-95 HONDA CIVIC 1.6L*****

TOOLS REQUIRED

Pliers
Ratchet 8mm, 10mm, 11mm, Deep Socket
Phillips Screwdriver
Flat Screwdriver
6" Extension

REMOVAL OF STOCK INTAKE AND INSTALLATION OF INTAKE SYSTEM

1. Locate and loosen clamp on the throttle body securing the OEM intake tube.
2. Detach the harness and hoses clipped on the OEM intake tube.
3. Locate and remove the crankcase breather hose from the OEM intake tube.
4. In front of the factory air box remove the air chamber by pulling upwards.
5. Locate the three 10mm bolt securing the factory air box to the chassis and remove bolts.
6. Remove the factory air box and intake tube from vehicle.
7. **PLEASE MAKE SURE ENGINE IS COOL BEFORE BEGINNING ON REMAINING STEPS.**
8. Remove the crankcase plumbing and coolant plumbing tube from vehicle.
9. Replace the coolant hose that was just removed with provided 8mm heater hose.
10. On the throttle body install provided 2.50" / 2.75" reducer coupler with two hose clamps but only tighten down the clamp on the throttle body side as of now.

11. Install the DC Sports intake tube into the throttle body. Notice the welded bracket on the intake tube going towards the shock tower.
12. Install between bracket and the shock tower the vibration mount and align the intake tube.
13. With Provided nut and washer secure the intake tube on the vibration mount.
14. Check and make sure the intake tube is clear from obstructions and tighten remaining hose clamp on the throttle body.
15. With provided 10mm vacuum hose attach to intake tube nipple and other end to the crankcase breather vent on the valve cover.
16. Install the DC Sports filter onto the intake tube.
17. Installation is now complete check all work performed.

*****LIMITED 3 YEAR WARRANTY*****

DC Sports only warranty's intake systems due to poor workmanship. We do not cover normal wear and tear damages due to misuse or abuse. We do not warranty the finish of intake tubes.

Warranty covers the original owner of intake system by having proof of purchase. We have the right to void all warranty if you cannot provide the information needed by DC Sports. DC Sports does not cover any cost for installation or removal of products.

*****CAUTION*****

DC Sports does not assume any liability for damage caused by rain or floods causing the intake system for taking on water. We recommend that you remove the cold air intake system due to wet conditions.

*****WARRANTY CLAIMS*****

All warranty claims must be shipped prepaid by the customer to DC Sports. Warranty claims must have an RMA (Return Merchandise Authorization) number on the box or package will be refused and sent back to the shipper.

PARTS LIST

Quantity	Part Number	Part Description
1	DCSRP5516	SRI5516 INTAKE TUBE
1	DCCP250-275	2.50/2.75" COUPLER REDUCER
18"	DCHH8MM	8MM HEATER HOSE
10"	DCVH10MM	10MM VACUUM HOSE
1	DCCL250	2.50" CLAMP
1	DCCL275	2.75" CLAMP
1	DCVM6MM	M6 M/M VIBRA MOUNT
1	DC-RAF275	2.75" DC SPORTS FILTER PACK
1	TMTAG-CARBEO13	D-370-13 carb sticker
2	DCDECAL	DC SPORTS DECAL

THANK YOU FOR CHOOSING DC SPORTS