



DC Sports
13000 Temple Ave
City of Industry Ca, 91746
T. 626-937-6988
www.dcsports.com

SRI5524
SHORT RAM INTAKE INSTALLATION INSTRUCTIONS
2006-2011 HONDA CIVIC SI 2.0L

**!!! READ ALL INSTRUCTION THOROUGHLY BEFORE BEGINNING
INSTALLATION. FAILURE TO DO SO MAY RESULT IN COSTLY ENGINE
AND/OR SYSTEM DAMAGE!!!**

*****IF UNSURE ABOUT INTAKE SYSTEM INSTALLATION PLEASE HAVE A
REPUTABLE PERFORMANCE SHOP OR A LICENCED MECHANIC
INSTALL THIS SYSTEM*****

*****FOR YOUR SAFETY, ALLOW ENGINE TO COOL FOR AT LEAST AN
HOUR BEFORE BEGINNING INSTALLATION*****

*****PLEASE CHECK AND MAKE SURE ALL HARDWARE IS PRESENT
BEFORE INSTALLATION. PARTS LIST ON LAST PAGE*****

A.R.B INFORMATION

*****THIS DC SPORTS INTAKE ARE CARB EXEMPT
PER EO#D-370-15 FOR 06-09 HONDA CIVIC SI ONLY*****

TOOLS REQUIRED

**Ratchet 10mm, 11mm Deep Socket
Flat Screwdriver
Phillips Screwdriver
Pliers
12" Extension**

REMOVAL OF STOCK INTAKE AND INSTALLATION OF INTAKE SYSTEM

1. Unplug negative terminal from car battery. Then proceed to remove the positive terminal.
2. Unclip wire harness attached to car battery tie down.
3. Unscrew battery tie down to loosen and remove battery tie down.
4. Remove car battery and under tray from vehicle.
5. Loosen the clamps holding the factory intake tube from the throttle body and the OEM air box.
6. Remove the harness plug attached to the air mass flow sensor by pressing down and pulling away.
7. Unclip the mass air flow sensor harness from the factory air box.
8. On the factory intake tube remove the vacuum hose and crankcase plenum by pressing down on the small clamps and pulling away.
9. Remove the factory intake tube from vehicle.
10. Locate and remove the two 10mm bolts securing the air inlet tube to the battery tray on the chassis.

11. Release the two harnesses attached to the air inlet tube.
12. Remove the air inlet tube from vehicle.
13. Locate the two 10mm bolts securing the factory air box to chassis and remove.
14. Remove factory air box from vehicle.
15. **WARNING ENGINE SHOULD BE COOL BEFORE WORKING ON THESE NEXT STEPS**
16. Remove the coolant and crankcase plenum from vehicle.
17. Install the 8mm heater hose in place of the factory plenum and reuse factory clamps.
18. Install the 45 degree 2.75" coupler and two clamps to throttle body but do not tighten down at this time.
19. Remove mass air flow sensor from factory air box.
20. Install the mass air flow sensor to intake tube with the two machine screws provided.
21. Install the air filter onto the intake tube away from the mass air flow sensor.
22. Slip intake tube onto the 45 degree coupler.
23. Notice the welded bracket off the intake tube. Install the male/female vibration mount on the OEM black bracket where the welded bracket off the intake tube meets.
24. Secure the welded bracket on to vibration mount with washer and nut provided.
25. Tighten both clamps on the coupler at the throttle body.
26. Attach the factory vacuum hose onto the intake tube and reuse the factory clamp.
27. Install the 15.9mm vacuum hose onto the intake tube and the other end onto the valve cover.
28. Plug the harness into the mass air flow sensor.
29. Reinstall the battery into the vehicle in reverse order of removal.
30. Installation is now complete check all work performed.

*****LIMITED 3 YEAR WARRANTY*****

DC Sports only warranty's intake systems due to poor workmanship. We do not cover normal wear and tear damages due to misuse or abuse. We do not warranty the finish of intake tubes.

Warranty covers the original owner of intake system by having proof of purchase.

**We have the right to void all warranty if you cannot provide the information needed by DC Sports.
DC Sports does not cover any cost for installation or removal of products.**

*****CAUTION*****

DC Sports does not assume any liability for damage caused by rain or floods causing the intake system for taking on water. We recommend that you remove the cold air intake system due to wet conditions.

*****WARRANTY CLAIMS*****

**All warranty claims must be shipped prepaid by the customer to DC Sports.
Warranty claims must have an RMA (Return Merchandise Authorization) number on the box or package will be refused and sent back to the shipper.**

PARTS LIST

Quantity	Part Number	Part Description
1	DCSRP5524	SRI5524 INTAKE TUBE
16"	DCHH8MM	8MM HEATER HOSE
16"	DCVH159MM	15.9MM VACUUM HOSE
1	DCCP27545	2.75" 45 DEGREE COUPLER
2	DCCL275	2.75" CLAMP
2	DCPS8	8MM PHILLIPS MACHINE SCREWS
1	DCVMM6MF	M6 M/F VIBRA MOUNT
1	DC-RAF300	3.00" DC SPORTS FILTER PACK
1	TMTAG-CARBE015	D-370-15 carb sticker
2	DCDECAL	DC SPORTS DECALS

THANK YOU FOR CHOOSING DC SPORTS