



DC Sports
13000 Temple Ave
City of Industry Ca, 91746
T. 626-937-6988
www.dcsports.com

SRI5525
SHORT RAM INTAKE INSTALLATION INSTRUCTIONS
2006-2011 HONDA CIVIC DX, LX, EX 1.8L

**!!! READ ALL INSTRUCTION THOROUGHLY BEFORE BEGINNING
INSTALLATION. FAILURE TO DO SO MAY RESULT IN COSTLY ENGINE
AND/OR SYSTEM DAMAGE!!!**

*****IF UNSURE ABOUT INTAKE SYSTEM INSTALLATION PLEASE HAVE A
REPUTABLE PERFORMANCE SHOP OR A LICENCED MECHANIC
INSTALL THIS SYSTEM*****

*****FOR YOUR SAFETY, ALLOW ENGINE TO COOL FOR AT LEAST AN
HOUR BEFORE BEGINNING INSTALLATION*****

*****PLEASE CHECK AND MAKE SURE ALL HARDWARE IS PRESENT
BEFORE INSTALLATION. PARTS LIST ON LAST PAGE*****

A.R.B INFORMATION

*****THIS DC SPORTS INTAKE ARE CARB EXEMPT PER EO#D-370-15*****

TOOLS REQUIRED

**Ratchet 10mm, 11mm Deep Socket
Flat Screwdriver
Phillips Screwdriver
Pliers
6" Extension**

REMOVAL OF STOCK INTAKE AND INSTALLATION OF INTAKE SYSTEM

1. Unplug the factory harness from the mass air flow sensor by pressing on the clip and pulling away.
2. Remove mass air flow sensor harness from factory air box.
3. Unlatch the four clips holding the factory air box cover and remove from lower section air box.
4. Locate the two 10mm bolts holding the lower air box from the chassis.
5. Loosen the clamp holding the factory intake tube to the OEM air box.
6. Pull and remove the factory crankcase plenum hose from OEM intake tube by depressing small clamp.
7. Remove lower factory air box from the engine bay.
8. Unscrew negative battery terminal and then unscrew the positive battery terminal. Loosen the factory battery tie down and remove car battery.
9. Locate two 10mm bolts holding the factory air inlet tube to the chassis and remove bolts. Remove air inlet tube from vehicle.

10. Loosen the clamp securing the factory small intake tube on the throttle body. Remove intake tube from vehicle.
11. **WARNING ENGINE SHOULD BE COOL BEFORE WORKING ON THESE NEXT STEPS**
12. Remove coolant and crankcase plenum from vehicle.
13. Install the 8mm hose in place of the OEM plenum that was just removed and reuse the factory clamps.
14. Remove the mass air flow sensor from the factory air box and install on the intake tube with the machine screws provided.
15. Install the 2.50" straight coupler provided with two clamps on the throttle body. But only tighten down the clamp on the throttle body side at this point.
16. Slide intake tube onto the throttle body coupler.
17. Notice the welded bracket on the intake tube. The bracket sits near the ECM locate the 10mm on the ECM and remove bolt.
18. Install the L bracket provided and reuse the 10mm bolt. **"SEE PICTURE A"**
19. Install the vibration mount onto the L bracket with provided nut and washer.
20. Align the intake tube welded bracket to the vibration mount and use washer and nut provided and tighten down.
21. Reinstall the car battery in reverse order from step 8.
22. Tighten down the remaining clamp on the throttle body.
23. Install the crankcase breather hose onto the nipple on the intake pipe and the other end onto the valve cover.
24. Plug the harness into the mass air flow sensor.
25. Install the air filter onto the intake tube.
26. Installation is now competed, Double check all work performed.

*****LIMITED 3 YEAR WARRANTY*****

DC Sports only warranty's intake systems due to poor workmanship. We do not cover normal wear and tear damages due to misuse or abuse. We do not warranty the finish of intake tubes.

**Warranty covers the original owner of intake system by having proof of purchase.
We have the right to void all warranty if you cannot provide the information needed by DC Sports.
DC Sports does not cover any cost for installation or removal of products.**

*****CAUTION*****

DC Sports does not assume any liability for damage caused by rain or floods causing the intake system for taking on water. We recommend that you remove the cold air intake system due to wet conditions.

*****WARRANTY CLAIMS*****

**All warranty claims must be shipped prepaid by the customer to DC Sports.
Warranty claims must have an RMA (Return Merchandise Authorization) number on the box or package will be refused and sent back to the shipper.**

PARTS LIST

Quantity	Part Number	Part Description
1	DCSRP5525	SRI5525 INTAKE TUBE
18"	DCHH8MM	8MM HEATER HOSE
8"	DCVH158MM	15.9MM VACUUM HOSE
1	DCCP250	2.50" STRAIGHT COUPLER
2	DCCL250	2.50" CLAMP
2	DCPS8	8MM PHILLIPS MACHINE SCREWS
1	DCVM6MM	M6 M/M VIBRA MOUNT
1	DCFW1	FENDER WASHER
1	DCLNM6	M6 NYLON LOCK NUT
1	DCB5525	SRI5525 L BRACKET
1	DC-RAF250	2.50" DC SPORTS FILTER PACK
1	D-370-13	D-370-15 ARB Sticker
2	DCDECAL	DC SPORTS DECALS

THANK YOU FOR CHOOSING DC SPORTS