



13000 Temple Ave. City of Industry, CA 91746

Tech line (626) 968-5147 Main line (800) 237-7560
www.dcsports.com

SRI6003
SHORT RAM INTAKE INSTALLATION INSTRUCTIONS
1990-1993 ACURA INTEGRA RS, LS, GS

NOTES: NON ABS

**!!! READ ALL INSTRUCTION THOROUGHLY BEFORE BEGINNING
INSTALLATION. FAILURE TO DO SO MAY RESULT IN COSTLY ENGINE
AND/OR SYSTEM DAMAGE!!!**

*****IF UNSURE ABOUT INTAKE SYSTEM INSTALLATION PLEASE HAVE A
REPUTABLE PERFORMANCE SHOP OR A LICENCED MECHANIC
INSTALL THIS SYSTEM*****

*****FOR YOUR SAFETY, ALLOW ENGINE TO COOL FOR AT LEAST AN
HOUR BEFORE BEGINNING INSTALLATION*****

*****PLEASE CHECK AND MAKE SURE ALL HARDWARE IS PRESENT
BEFORE INSTALLATION. PARTS LIST ON LAST PAGE*****

A.R.B INFORMATION

*****THIS DC SPORTS INTAKE ARE CARB EXEMPT
PER EO#D-370-13 FOR 90-93 Acura Integra 1.8L ONLY*****

TOOLS REQUIRED

**Pliers
Ratchet 10mm, 11mm Deep Socket
Phillips Screwdriver
6" Extension**

REMOVAL OF STOCK INTAKE AND INSTALLATION OF INTAKE SYSTEM

1. On the throttle body loosen clamp securing the factory intake tube.
2. On the factory intake tube unplug all vacuum lines that are attached.
3. Unclip four clamps securing the upper section of the factory air box.
4. Remove entire factory intake tube and upper section of the air box from vehicle.
5. Remove stock air filter from vehicle.
6. Locate and remove three 10mm bolts securing the factory air box to the chassis.
7. **CAUTION: MAKE SURE ENGINE IS COOL BEFORE WORKING ON THESE NEXT STEPS.**
8. Remove factory vacuum line and hard line from the crankcase.
9. Attached to the vacuum hard line is a 8mm factory coolant line remove and replace with provided 8mm heater hose.
10. Loosely install provided reducer coupler into the throttle body with two clamps.
11. Carefully slide the intake tube into the throttle body coupler.
12. Notice the welded bracket on the intake.

13. Install provided vibration mount between the welded bracket on the intake and on the factory bracket attached to the chassis.
14. Slide the welded bracket onto the vibration mount and secure with provided nut and washer.
15. Install the DC Sports filter onto the intake tube.
16. Tighten all clamps on the throttle body securing the intake tube.
17. Install provided 10mm vacuum hose from the crankcase to the intake tube vent.
18. **NOTE:** 90-91 models requires a tee fitting and 4mm vacuum hose for the cold start solenoid.
19. Install is now complete double check all work performed.

*****LIMITED 10 YEAR WARRANTY*****

DC Sports only warranty's intake systems due to poor workmanship. We do not cover normal wear and tear damages due to misuse or abuse. We do not warranty the finish of intake tubes.

Warranty covers the original owner of intake system by having proof of purchase. We have the right to void all warranty if you cannot provide the information needed by DC Sports. DC Sports does not cover any cost for installation or removal of products.

*****CAUTION*****

DC Sports does not assume any liability for damage caused by rain or floods causing the intake system for taking on water. We recommend that you remove the cold air intake system due to wet conditions.

*****WARRANTY CLAIMS*****

All warranty claims must be shipped prepaid by the customer to DC Sports. Warranty claims must have an RMA (Return Merchandise Authorization) number on the box or package will be refused and sent back to the shipper.

PARTS LIST

Quantity	Part Number	Part Description
1	DCSRP6003	SRI6003 INTAKE TUBE
12'	DCVH4MM	4MM VACUUM HOSE
15"	DCHH8MM	8MM HEATER HOSE
10"	DCVH10MM	10MM VACUUM HOSE
1	DCCP275-300	2.75/3.00" COUPLER REDUCER
1	DCCL275	2.75" CLAMP
1	DCCL300	3.00" CLAMP
1	DCVC9MM	9MM ID VACUUM CAP
1	DCVM6MM	M6 M/M VIBRA MOUNT
1	DCLNM6	M6 NYLON LOCK NUT
1	DCFW1	FENDER WASHER
1	DCF300	3.00" DC Sports FILTER PACK
2	DCDECAL	DC Sports DECALS

THANK YOU FOR CHOOSING DC SPORTS