



**DC Sports**  
13000 Temple Ave  
City of Industry Ca, 91746  
T. 626-937-6988  
[www.dcsports.com](http://www.dcsports.com)

---

**SRI6006**  
**SHORT RAM INTAKE INSTALLATION INSTRUCTIONS**  
**1994-2001 ACURA INTEGRA RS, LS, 1997-2001 TYPE-R 1.8L**

**!!! READ ALL INSTRUCTION THOROUGHLY BEFORE BEGINNING  
INSTALLATION. FAILURE TO DO SO MAY RESULT IN COSTLY ENGINE  
AND/OR SYSTEM DAMAGE!!!**

**\*\*\*IF UNSURE ABOUT INTAKE SYSTEM INSTALLATION PLEASE HAVE A  
REPUTABLE PERFORMANCE SHOP OR A LICENCED MECHANIC  
INSTALL THIS SYSTEM\*\*\***

**\*\*\*FOR YOUR SAFETY, ALLOW ENGINE TO COOL FOR AT LEAST AN  
HOUR BEFORE BEGINNING INSTALLATION\*\*\***

**\*\*\*PLEASE CHECK AND MAKE SURE ALL HARDWARE IS PRESENT  
BEFORE INSTALLATION. PARTS LIST ON LAST PAGE\*\*\***

**A.R.B INFORMATION**  
**\*\*\*THIS DC SPORTS INTAKE ARE CARB EXEMPT  
PER EO#D-370-13 FOR 1994-2001 INTEGRA RS LS AND 1997-2001 INTEGRA  
TYPE-R\*\*\***

**TOOLS REQUIRED**  
Pliers  
Ratchet 10mm, 11mm Deep Socket  
Phillips Screwdriver  
Flat Screwdriver

**REMOVAL OF STOCK INTAKE AND INSTALLATION OF INTAKE SYSTEM**

1. With screwdriver loosen the OEM throttle body clamp.
2. Unclip MAP sensor harness on the throttle body and unclip vacuum line mounted on the OEM intake tube.
3. Use pliers to squeeze small clamp holding crank case breather tube on factory tube and remove on intake side.
4. Remove factory intake duct by sliding away from air box.
5. Locate three 10mm bolts holding the air box to the chassis and remove.
6. Remove factory air box
7. Double check to make sure engine is cool remove the vacuum and coolant line plenum.
8. Replace the factory coolant line that was just removed in step 7. with the 13" 8mm hose and reuse the factory clamps
9. At the throttle body install the reducer coupler and two clamps but make sure that you only tighten the

- clamp on the throttle body side.
10. Slowly slip on the intake tube into the coupler and you will see the bracket off the tube that extends to the chassis of the car and install the vibration mount, after this point be sure to lock the bracket down with the washer and nut provided. ( **NOTE** If car has ABS remove bolt and replace with vibration mount)
  11. Tighten down the other clamp from the throttle body towards intake tube.
  12. Install 10" 10mm hose from the nipple of the intake tube to the nipple off the valve cover.
  13. **Thoroughly wipe down filter inlet until all excess oil from the tooling has been removed.**  
Install air filter to the lower section of the intake tube.

**\*\*\*LIMITED 3 YEAR WARRANTY\*\*\***

**DC Sports only warranty's intake systems due to poor workmanship. We do not cover normal wear and tear damages due to misuse or abuse. We do not warranty the finish of intake tubes.**

**Warranty covers the original owner of intake system by having proof of purchase. We have the right to void all warranty if you cannot provide the information needed by DC Sports. DC Sports does not cover any cost for installation or removal of products.**

**\*\*\*CAUTION\*\*\***

**DC Sports does not assume any liability for damage caused by rain or floods causing the intake system for taking on water. We recommend that you remove the cold air intake system due to wet conditions.**

**\*\*\*WARRANTY CLAIMS\*\*\***

**All warranty claims must be shipped prepaid by the customer to DC Sports. Warranty claims must have an RMA (Return Merchandise Authorization) number on the box or package will be refused and sent back to the shipper.**

**PARTS LIST**

<b>Quantity</b>	<b>Part Number</b>	<b>Part Description</b>
1	DCSRP6006	SRI6006 INTAKE TUBE
13"	DCHH8MM	8MM HEATER HOSE
12.5"	DCVH10MM	10MM VACUUM HOSE
1	DCCP275-300	2.75/3.00" COUPLER REDUCER
1	DCCL275	2.75" CLAMP
1	DCCL300	3.00" CLAMP
1	DCVMM6MM	M6 M/M VIBRA MOUNT
1	DCF300	3.00" DC SPORTS FILTER PACK
1	TMTAG-CARBEO13	D-370-13 CARB sticker
2	DCDECAL	DC SPORTS DECALS

**THANK YOU FOR CHOOSING DC SPORTS**