



DC Sports
13000 Temple Ave
City of Industry Ca, 91746
T. 626-937-6988
www.dcsports.com

SRI6514
SHORT RAM INTAKE INSTALLATION INSTRUCTIONS
2002-2006 ACURA RSX TYPE S 2.0L

**!!! READ ALL INSTRUCTION THOROUGHLY BEFORE BEGINNING
INSTALLATION. FAILURE TO DO SO MAY RESULT IN COSTLY ENGINE
AND/OR SYSTEM DAMAGE!!!**

*****IF UNSURE ABOUT INTAKE SYSTEM INSTALLATION PLEASE HAVE A
REPUTABLE PERFORMANCE SHOP OR A LICENCED MECHANIC
INSTALL THIS SYSTEM*****

*****FOR YOUR SAFETY, ALLOW ENGINE TO COOL FOR AT LEAST AN
HOUR BEFORE BEGINNING INSTALLATION*****

*****PLEASE CHECK AND MAKE SURE ALL HARDWARE IS PRESENT
BEFORE INSTALLATION. PARTS LIST ON LAST PAGE*****

A.R.B INFORMATION

*****THIS DC SPORTS INTAKE ARE CARB EXEMPT
PER EO#D-370-15 FOR 02-06 ACURA RSX TYPE-S *****

TOOLS REQUIRED

**Pliers
Ratchet 10mm, 11mm, Deep Socket
Phillips Screwdriver
Flat Screwdriver**

REMOVAL OF STOCK INTAKE AND INSTALLATION OF INTAKE SYSTEM

1. Locate two 10mm bolts holding engine cover and remove bolts and cover.
2. On each end of the factory intake tube loosen both clamps. One on the throttle body side and air box side.
3. Unplug and remove the OEM air mass sensor on the factory intake tube.
4. Remove the OEM vacuum hose from the factory intake tube.
5. With everything unplugged from the factory intake tube remove the factory intake tube.
6. Locate one 10mm nut and two 10mm bolts that holds the OEM air box to the chassis and remove.
7. Lift up factory air box remove the crankcase breather tube that is attached to the air box and remove the air inlet tube from air box.
8. Locate 10mm bolt attaching the air inlet tube to the radiator support and remove air inlet tube.
9. Attach the 90-degree elbow coupler onto the throttle body and the two clamps but do not tighten the clamps.
10. Install the air filter onto the intake tube.
11. Install the intake tube on the coupler attached on the throttle body. You will see the bracket that is

- welded on the intake tube attach the vibration mount provided onto the bracket and line up the intake tube. Install the washer and 10mm bolt provided with the vibration mount.
12. Tighten the clamp on the coupler towards the intake side.
 13. Before you tighten down the clamp toward the throttle body side. Unplug the harness then tighten the clamp afterwards be sure that you plug the harness back in.
 14. Slip the factory vacuum line back into the intake system.
 15. Slip the 12mm vacuum hose provided into the crank case and also into the intake tube.
 16. Plug the air temp sensor back into the intake tube.
 17. Reinstall the engine cover with the two 10mm bolts as in step 1.

*****LIMITED 3 YEAR WARRANTY*****

DC Sports only warranty's intake systems due to poor workmanship. We do not cover normal wear and tear damages due to misuse or abuse. We do not warranty the finish of intake tubes.

Warranty covers the original owner of intake system by having proof of purchase. We have the right to void all warranty if you cannot provide the information needed by DC Sports. DC Sports does not cover any cost for installation or removal of products.

*****CAUTION*****

DC Sports does not assume any liability for damage caused by rain or floods causing the intake system for taking on water. We recommend that you remove the cold air intake system due to wet conditions.

*****WARRANTY CLAIMS*****

All warranty claims must be shipped prepaid by the customer to DC Sports. Warranty claims must have an RMA (Return Merchandise Authorization) number on the box or package will be refused and sent back to the shipper.

PARTS LIST

Quantity	Part Number	Part Description
1	DCSRP6514	SRI6514 INTAKE TUBE
3"	DCVH159MM	15.9MM VACUUM HOSE
1	DCCP27590	2.75" 90 DEGREE COUPLER
2	DCCL275	2.75" CLAMP
1	DCVMM6MF	M6 M/F VIBRA MOUNT
1	DCRG58	5/8" RUBBER GROMMET
1	DC-RAF350	3.5" DC SPORTS FILTER PACK
1	TMTAG-CARBE015	D-370-15 carb sticker
2	DCDECAL	DC SPORTS DECALS

THANK YOU FOR CHOOSING DC SPORTS