



DC Sports
13000 Temple Ave
City of Industry Ca, 91746
T. 626-937-6988
www.dcsports.com

SRI7048
SHORT RAM INTAKE INSTALLATION INSTRUCTIONS
2012-2013 HONDA CIVIC SI 2.4L
2013 ACURA ILX

NOTE: MANUAL TRANSMISSION ONLY

**!!! READ ALL INSTRUCTION THOROUGHLY BEFORE BEGINNING
INSTALLATION. FAILURE TO DO SO MAY RESULT IN COSTLY ENGINE
AND/OR SYSTEM DAMAGE!!!**

*****IF UNSURE ABOUT INTAKE SYSTEM INSTALLATION PLEASE HAVE A
REPUTABLE PERFORMANCE SHOP OR A LICENCED MECHANIC
INSTALL THIS SYSTEM*****

*****FOR YOUR SAFETY, ALLOW ENGINE TO COOL FOR AT LEAST AN
HOUR BEFORE BEGINNING INSTALLATION*****

*****PLEASE CHECK AND MAKE SURE ALL HARDWARE IS PRESENT
BEFORE INSTALLATION. PARTS LIST ON LAST PAGE*****

TOOLS REQUIRERD

Ratchet 10mm Deep Socket

Flat Screwdriver

Phillips Screwdriver

Pliers

12" Extension

Allen Set

REMOVAL OF STOCK INTAKE AND INSTALLATION OF INTAKE SYSTEM

1. Locate the small clamp securing the hard-vacuum line attached to the OEM rubber intake tube. Press clamp and carefully pull the hard line upwards.
2. Locate and unclip the harness attached to the MAF sensor.
3. Carefully unclip the green plug securing the harness to the OEM air box.
4. Loosen the two clamps securing the OEM intake tube from the throttle body and from the air box and remove intake tube.
5. Unclip the upper half of the OEM air box and remove from vehicle.
6. Locate the 10mm bolt securing the lower half of the air box and remove screw.
7. Unhook and remove the lower air box from vehicle. Please make sure that you also unhook the lower air box from the OEM snorkel. The OEM air snorkel will remain on the car.
8. **WARNING ENGINE SHOULD BE COOL BEFORE WORKING ON THESE NEXT STEPS.**

9. Locate and unclip the small clamps securing the hard line to the crankcase breather and also unclip the clamps securing the hard-line coolant line. Remove the vacuum/coolant hard line from vehicle. **“SEE PICTURE A”**
10. Replace the coolant hard line with provided 8mm heater hose and secure with provided clamps.
11. Install provided 2.75” to 3.00” reducer coupler onto the throttle body with provided clamps. Do not tighten the clamps at this time.
12. Install provided DC Sports filter onto the inlet side on the intake tube. Do not tighten the clamps at this time.
13. Loosely install the intake pipe onto the throttle body coupler. Do not tighten the clamps at this time.
14. Loosely install provided “L” bracket with provided M6 bolt to the side of the intake tube.
15. Loosely install provided M12 washer and nut to the transmission stud. **NOTE: DO NOT REMOVE THE OEM NUT SECURING THE TRANSMISSION. Provided “L” bracket will sit on top of the OEM nut. “SEE PICTURE B”**
16. Remove the MAF sensor from the OEM air box and install onto the DC Sports intake tube with provided allen screws.
17. Check for clearance and tighten all clamps and bolts from the throttle body and work your way to the filter.
18. Install provided 15.9MM vacuum hose from the crankcase breather to the intake breather tube.
19. Plug harness into the MAF sensor.
20. Installation is now completed check all work performed.

*****LIMITED 3 YEAR WARRANTY*****

DC Sports only warranty’s intake systems due to poor workmanship. We do not cover normal wear and tear damages due to misuse or abuse. We do not warranty the finish of intake tubes.

Warranty covers the original owner of intake system by having proof of purchase.

We have the right to void all warranty if you cannot provide the information needed by DC Sports. DC Sports does not cover any cost for installation or removal of products.

*****CAUTION*****

DC Sports does not assume any liability for damage caused by rain or floods causing the intake system for taking on water. We recommend that you remove the cold air intake system due to wet conditions.

*****WARRANTY CLAIMS*****

All warranty claims must be shipped prepaid by the customer to DC Sports.

Warranty claims must have an RMA (Return Merchandise Authorization) number on the box or package will be refused and sent back to the shipper.

PARTS LIST

Quantity	Part Number	Part Description
1	DCSRP7048	SRI7048 INTAKE TUBE
10"	DCHH8MM	8MM HEATER HOSE
9.5"	DCVH159MM	15.9MM VACUUM HOSE
1	DCCP275-300	2.75" TO 3.00" REDUCER COUPLER
1	DCCL275	2.75" CLAMP
1	DCCL300	3.00" CLAMP
2	DCAS8	8MM ALLEN MACHINE SCREWS
2	DCCLSM	.5" CLAMP
1	DCM6B	M6 X 1.00 X 14MM BOLT
1	DCHNM12	M12 X 1.25 HEX NUT
1	DCWHM12	M12 WASHER
1	DCBRK7048	L BRACKET SRI7048
1	DCF300	3.00" DC SPORTS FILTER PACK
2	DCDECAL	DC SPORTS DECALS

THANK YOU FOR CHOOSING DC SPORTS