





Step 1

 Turn key clockwise to unlock, releasing shackle.



Step 2

- Open shackle to 180°.
- Turn key back counter clockwise (past locked position) until it stops.



Step 3

- Remove shackle.
- Install guard, change shackles or use cable (see cable instructions).



Step 4

- Insert shackle to the marked groove (about 5/8 in) rotated out 180°.
- Turn key clockwise fully, then swivel shackle back into place to close.



iChange Tactical Padlock Cable Assembly Instructions



Step 1





- Turn key clockwise to open, release one end of cable.
 Turn key back counter clockwise past locked position until it stops.
 - Remove second end of cable.





- Turn key into counter clockwise position.
- Insert long tip of cable into noted deeper lock hole, with notch facing inward.



Step 4

- Turn key back clockwise.
- Insert second end of cable completely.
- Turn key back to lock.