WORKBRUTES G2 Tough & Durable PVC Overshoes



Workbrutes G2 protects expensive workboots from weather, mud, and harsh chemicals.

Workbrutes® G2 Easily Stretch Over Large Work Boots

Workbrutes G2 are wider and have more room in the toe for ideal fit over safety toe work boots or other large shoes, while the high quality PVC provides the ultimate protection from liquids, mud, and harsh chemical environments.

- Injection molded, seamless construction for 100% liquid proof protection.
- Expansion pleats in key entry areas for incredibly easy donning even on heavy-duty work boots.
- Unique thumb pocket and texturing at the top opening allows firm, no-slip grip for easy donning.
- Frigiflex PVC compound keeps overshoes highly stretchable and flexible in cold temperatures.
- Increased thickness in high wear areas such as the heel, toe and cleats for longer life.
- No lining for easy cleaning, laundering, and decontamination.
- Molded in button and two button holes for ideal fit and protection
- Two-stage PVC injection combines a high-stretch upper with durable, abrasion resistant outsole.
- Heavy duty heel kick for hands free removal.



Cleated Outsole:

Slip resistant, self cleaning, cleated outsole provides traction on a variety of surfaces and conditions.

Ideal Applications: Farm/Agriculture, Food Processing, Construction, Petroleum Refineries, Municipalities, Transportation, Hazardous Waste Cleanup, and General Industry.

Chemical Resistance: Hydrocarbons, some exposure to fats, and certain acids and alkalis. Not recommended for use with ketones, aldehydes, and similar solvents.



#4035 - 9/18



est. 1896









