

# BLUE RIDGE INSTALL GUIDE

## **FOR: BRONCO ATTIC**

Welcome! This installation isn't rocket science but it is kind of like karate - you can hurt yourself or break something if you don't pay attention. Used properly, this Install Guide will tell you all you need to know - like Yoda, but with better grammar.

If you have any trouble, contact us for product support: blueridgeoverlandgear.com/pages/contact-us

#### TOOLS NEEDED: 8mm Socket & Wrench





#### **STEP #1**

Remove 4 trim screws using the socket wrench as shown.



#### **STEP #2**

Take the 4 anchor tabs and install them where you removed the trim screws in Step #1, using the same hardware.



### **STEP #3**

Hang the attic by attaching the flat loops on each corner to the G-Hooks on each anchor tab. Adjust until attic is taut.





## BLUE RIDGE INSTALL GUIDE: BRONCO ATTIC

#### continued



#### **STEP #4**

Adjust paracord for desired tension and fasten with the barrel lock.



#### **STEP #5**

Impress your friends and family by always having your rain gear and other *lightweight* gear organized. Go explore!



Thank you for choosing Blue Ridge Overland Gear. We are handcrafting the toughest bags and organizers for your adventurous life - right here in Bedford, Virginia, USA. It's not just American made, it's 'Blue Ridge Built'!

This product comes with our <u>Rugged Lifetime Warranty</u>. If you have any trouble, contact us for product support: BlueRidgeOverlandGear.com/pages/contact-us