



INSTALL GUIDE

FOR: JEEP JLU ATTIC (WARNING: DOES NOT FIT A JEEP JL!)

Welcome! This installation isn't rocket science but it is kind of like karate - you can hurt yourself or break something if you don't pay attention. Used properly, this Install Guide will tell you all you need to know - like Yoda, but with better grammar.

If you have any trouble, contact us for product support: blueridgeoverlandgear.com/pages/contact-us

TOOLS YOU NEED: Star Bit Screwdriver



STEP #1

Remove the 4 trim screws as shown.



STEP #2

Insert each screw through the hole in the 4 anchor straps and tighten the trim screws back in place.



GO TO NEXT PAGE >



continued



STEP #3

Attach the 'G' shaped hooks on the straps to corners of the attic, as shown, with the para-cord facing down.

STEP #4

Adjust straps to pull attic tight. Additionally, you can use the paracord to further adjust for your desired tension.



STEP #5

Now that you have installed your vehicle attic, please consider the following:

- Studies have shown installing a vehicle attic could make your head look smaller (for all you large-browed brainiacs out there).
- An attic may lead to an improved love life. Your dates will think you are a super-organized person!
- Never dig for blankets or raincoats ever again. It's also perfect for other loose, lightweight gear.

Thank you for choosing Blue Ridge Overland Gear. We are handcrafting the toughest bags and organizers for your adventurous life - right here in Bedford, Virginia, USA. It's not just American made, it's 'Blue Ridge Built'!

This product comes with our Rugged Lifetime Warranty. If you have any trouble, contact us for product support: blueridgeoverlandgear.com/pages/contact-us