

COMPONENTS

- ◆ Notched Louvre Blade 55mm. Blade length is determined by overall opening (including the 50mm styles) minus 60mm
- ◆ Slotted Post Inserts Pairs (left and Right) with Bush fitted in left and locking plug fitted in Right- (50x50x2 Routed Box.)
- ◆ Centre Post Insert (CP) – 50x50x2 Rad Double Routed. Fit Bush plugs only to right side slots. (DO NOT FIT LOCKING PLUG TO LEFT SIDE SLOTS UNITL YOU HAVE INSERTED SLATS TO RIGHT SIDE)
- ◆ 57x50 or 55x20 U channel top and bottom

ASSEMBLY INSTRUCTIONS

1. Always Work from the face side of the panel. Right side panel installed first followed by left side
2. Install Left and Right Style to pier or Post.
3. Fit U channels top and bottom.
4. Fit centre Upright (if required. Panels over 1200W)
5. Insert all louvre blades top down into the right-side panel. Slide the unnotched side of the blade left into the slot and pulling back to the right slot until slat locks.

NOTE: Important that the notch in the slat is always on the bottom right when installing from the face side of the panel

6. Insert Uniplug 4 (Locking Plug) into the left side of the CP (centre Post) and Insert Uniplug 3 (bush) into the left SPI.
7. Insert all louvre blades top down into the left side panel. Slide the unnotched side of the blade left into the slot and pulling back to the right slot until slat locks.

NOTE: Important that the notch in the slat is always on the bottom right when installing from the face side of the panel

