

Part #
02010/02011

GSXR 600/750/1000 Frame Protector Fitting Instructions



Fig 1

Remove bolts at front of fuel tank, and prop up tank.

Remove fairing bolts circled in Fig 1.

Remove fairing brackets on frame and coolant tank, and cable guide at front left of frame.

Slide frame protectors behind ram air scoops and sit in position. (loosening nose cone fasteners may help as will make it possible to move ram air scoops forward)

When frame protectors are in place simply replace all fasteners, then use self tapping screw supplied to secure the front of left side protector, this screw goes into small hole at front of frame just under front of tank.

Then replace fairing bolts and secure tank.