

## **ZX6 Carbon frame guards**

**Part # 02310/02311**

### **Fitting kit includes**

Carbon fibre frame guards  
12 x Self-adhesive pads – CTAP0051

### **Fitting instructions:**

Remove single bolt on “ram air” covers, Lift covers up to remove.  
(these covers are located at front of tank on both sides).

Slide frame guards down between frame and fairing, The guards can only fit in one position and therefore it should be obvious when correctly fitted. When happy with fit attach guards with self adhesive pads supplied.

When guards have been attached, replace “ram air” covers and tighten bolts.

