

| Stick-Fit | 054241 BMW R1200RS Extenda Fenda Fitting Instructions

Please note: this Extenda Fenda is fitted externally


When installation is complete the bike must be left overnight before riding
This adhesive tape takes 12 hours to cure

- Remove the front guard from the bike - noting the position of any brake/ABS lines.
- Clean the outside face of the mudguard with hot soapy water - dry thoroughly.
- Using the alcohol wipe provided, wipe the contact face of the Extenda Fenda and mudguard. - *this maximises adhesion between the Extenda Fenda and mudguard.*
- Starting at the outer corners and finishing in the middle, attach the adhesive pads to the Extenda Fenda. **'Fig 1' gives an idea of the layout needed.** Position pads about 3mm away from the deepest part of the rebate in the Extenda Fenda - avoid overlaps.

Before removing the backing film, offer up the Extenda Fenda to the mudguard to check fit

- Remove the backing tape from the adhesive pads.
- Now install the Extenda Fenda onto the mudguard ensuring that the rebate in the Extenda Fenda is aligned with the edge of the mudguard.
- When satisfied that the Extenda Fenda is correctly aligned, place the guard on a soft surface (e.g a towel) and apply pressure for 30 seconds to ensure full contact between the Extenda Fenda and mudguard.
- Check for any clicking sounds when pressing on the Extenda Fenda, this sound means that a pad isn't stuck down properly (Small clamps can be used to apply pressure).
- Now attach the two clips provided to each extreme end of the Extenda Fenda, this will ensure the best possible adhesion in the most critical areas. **See 'Fig 2'**
- After the 12 hours curing time, the mudguard can be re-fitted to the bike.

Specific diagram for 054241



Visit '[youtube.com/pyramidplastix](https://www.youtube.com/pyramidplastix)' for our video tutorial on fitting a Stick-Fit Extenda Fenda

Alternatively you can contact us:
sales@pyramid-plastics.co.uk
+44 (0)1427 677990

www.pyramid-plastics.co.uk