

# PYRAMID



## 070403 Suzuki GSX-S1000 & Katana Hugger Fitting Instructions

Kit Includes:

3X M6 X 16mm Flange Head Bolts CBOLM60008

Please note: it is advised although not necessary that the rear wheel is removed for fitment of the Pyramid Hugger. Doing this will make the removal of the OEM Hugger & fitment of the Pyramid Hugger easier.

- Remove the existing mudguard.
- Feed the hugger over the tyre and into position. Fix the front mounting point loosely using either the original bolt or one of the M6x16mm bolts provided.
- Next loosely fasten the two side mounting points using the M6 X 16mm bolts provided.
- Push the brake hose mounting clip into the hole in the hugger.
- Check the alignment of the hugger and fully tighten all the mounting points. Make sure to always check all fixings periodically.

Got questions?  
sales@pyramid-plastics.co.uk  
+44 (0)1427 677990  
www.pyramid-plastics.co.uk

Follow us on social media and feel free to leave us a review!



# PYRAMID



## 070403 Suzuki GSX-S1000 & Katana Hugger Fitting Instructions

Kit Includes:

3X M6 X 16mm Flange Head Bolts CBOLM60008

Please note: it is advised although not necessary that the rear wheel is removed for fitment of the Pyramid Hugger. Doing this will make the removal of the OEM Hugger & fitment of the Pyramid Hugger easier.

- Remove the existing mudguard.
- Feed the hugger over the tyre and into position. Fix the front mounting point loosely using either the original bolt or one of the M6x16mm bolts provided.
- Next loosely fasten the two side mounting points using the M6 X 16mm bolts provided.
- Push the brake hose mounting clip into the hole in the hugger.
- Check the alignment of the hugger and fully tighten all the mounting points. Make sure to always check all fixings periodically.

Got questions?  
sales@pyramid-plastics.co.uk  
+44 (0)1427 677990  
www.pyramid-plastics.co.uk

Follow us on social media and feel free to leave us a review!

