

# **CBR600 99> & SPORT HUGGER**

## **Part # 07118**

### **Fitting kit:**

|                                 |            |
|---------------------------------|------------|
| 2 x M6 x 20mm button allen bolt | CBOLM60009 |
| 2 x M6 x 12mm button allen bolt | CBOLM60007 |
| 4 x M6 big nylon washer         | CWASM60004 |
| 4 x M6 s/steel washer           | CWASM60001 |

### **Fitting instructions:**

In order to position the hugger it is necessary to remove the left side pillion foot rest hanger.

Remove the original chain guard.

Remove the bolts that secure the two brake hose clips on the right side of the swing arm.  
(Do not discard the clips).

Position the hugger.

**In the first instance, do not fully tighten the fasteners**

**Use loctite or a similar thread retaining compound on all fasteners.**

Using the shorter bolts, with s/steel and nylon washers, secure the hugger to the chain guard tabs.

Use the longer bolts, with s/steel and nylon washers, to secure the hugger at the hose clip mounts, making sure that the clips are in position between the hugger and the swing arm.

Check hugger alignment before finally tightening all fasteners.

**Please note: check hugger alignment and fasteners periodically.**