

071234 Honda CB 750 Hornet Hugger Fitting Instructions

Kit Includes:

1X	C071234	Hugger Moulding	
1X	CFK071234	Bracket	
2X	CRUB0001	Rubber Strip (cut to 90mm - 180mm total)	(pre-cut by Pyramid)
2X	CBOLM60008	M6 X 16mm Stainless Bolt	
2X	CGROM60001	Rubber Grommet	
2X	CSPAM60004	M6 Steel Collar (8mm)	
2X	CBOLM50008	M5 X 16mm Stainless Bolt	
2X	CNUTM50003	M5 Stainless Serrated Nut	
2X	CWASM50001	M5 Washer	
1X	CFOA0002	Foam Strip (40mm length)	(pre-cut by Pyramid)

Any questions?
sales@pyramid-plastics.co.uk
 +44 (0)1427 677990
www.pyramid-plastics.co.uk



Follow us on social media and feel free to leave us a review!

- To gain better access to the rear swingarm, it is best to remove the exhaust.
- Remove the OEM chainguard.
- Trim and attach the **rubber strips** as shown in **Fig 1**.
- Install the **rubber grommets** and **M6 steel collars** in the two holes on the chainguard side of the Pyramid Hugger (**see Fig 2 below**). Attach the **40mm foam strip** provided to the bracket (**see Fig 3 below**).
- The bracket supplied with the Pyramid Hugger is attached on the right-hand side of the bike. Remove the OEM bolts and fit the bracket using the same OEM bolts (**see Fig 4 below**).
- Loosely attach the Pyramid Hugger to the bracket using **two M5 X 16mm stainless bolts**, **two M5 plastic washers** and **two M5 stainless serrated nuts** (**see Fig 4 below**).
- Loosely attach the chainguard side of the Pyramid Hugger using the remaining **two M6 X 16mm stainless bolts** (fitted through the previously installed rubber grommets and M6 steel collars).
- **Fully tighten all mounting points** and then re-install the exhaust.
- **Check all fixings periodically**.

