

Part # 07140



## CB1300 Hugger Fitting Instructions

### Fitting kit contents

- 1 x hugger
- 2 x 430 x 7.6mm Black cable ties – CAB0430A

### Fitting Instructions.

1. Thread the cable ties through the hugger using the pre-cut slots, Starting from the front go through the bottom slot and the back through the top slot. (see fig 1.)
2. Locate the hugger on the swinging arm spar, in front of the rear wheel. This can be made easier if the rear wheel is adjusted backwards slightly.
3. Tighten the cable ties just enough to hold in position, it is important at this point to ensure that there is an equal spacing between the hugger and both sides of the tyre to prevent rubbing.
4. Once in position, tighten the cable ties to secure the hugger in place.

