



Fazer1000 Hugger

Part # 07219

Hugger Fitting Instructions

Fittings: a) 3x M6x16 Stainless steel allen bolts CBOLM60008
 b) 3x Black plastic washers CWASM60003

General Information.

As with all huggers this model is designed to sit close to the tyre and should not be used with an oversized tyre. When fitting is complete the Hugger should sit centrally over the tyre when viewed from the rear. The tolerance in the right hand side mounting bracket allows adjustment to achieve this. As with all accessories the mountings should be checked for tightness.

The Job is easier with the bike on a paddock stand.

1. First remove the chain guard.
2. Remove the brake hose guide
3. Feed the hugger in over the wheel and position the right angle flange area underneath the brake hose.
4. Attach loosely to the chain side using 2x (a) and (b)
5. Attach to the right side by using 1x (a) and 1x (b) replacing the brake hose guide on top of the hugger flange

Fully tighten all fasteners checking left/right alignment over the tyre as you do so.
Re-tighten the rear break hose mounting clips.

Check position of hugger over tyre. If adjustment is required loosen all fasteners slightly to allow re-alignment.

NOTE!:

ALL PYRAMID PRODUCTS ARE DESIGNED USING THE FACTORY STANDARD BIKES WITH STANDARD TYRES ETC... SO ANY LARGER SIZE TYRES MAY AFFECT THE FIT.