

## Part # 07223

### XJR 1300 Hugger

#### Hugger Fitting Instructions

##### Fittings:

1x 80mm Foam Strip - CFOA0001

##### General Information.

As with all huggers this model is designed to sit close to the tyre and should not be used with an oversized tyre. When fitting is complete the hugger should sit centrally over the tyre when viewed from the rear. The tolerance in the right hand side mounting bracket allows adjustment to achieve this. As with all accessories the mountings should be checked for tightness. The foam strip provided is to be placed at the bottom tail end of the hugger.

\*\*\*\*\*

The Job is easier with the bike on a paddock stand.

1. First remove the chain guard.
2. Remove the brake hose guide.
3. Feed the hugger in over the wheel so the right angle flange piece is positioned close to the disc and push forward past inside of shock.  
(this should avoid contact with any other parts)
4. Lift brake hose over flange piece and attach using guide bracket and original bolt.
5. feed chain guard down side of wheel and through slot in hugger, attach using 2 original bolts and fully tighten.
6. Fully tighten bolt on other side.

Check position of hugger over tyre. If adjustment is required loosen all fasteners slightly to allow re-alignment.

#### NOTE!:

**ALL PYRAMID PRODUCTS ARE DESIGNED USING THE FACTORY STANDARD BIKES WITH STANDARD TYRES ETC... SO ANY LARGER SIZE TYRES MAY AFFECT THE FIT.**

