

Fitting kit includes

1 x 13mm Rubber Grommet and spacer – CGROM60001/CSPAM60006

3 x M6 x 16MM flange headed bolts. – CBOLM60008

Remove original hugger and chain guard.

Put Grommet and spacer in the hole on near side of the hugger.

Place the new hugger and bolts onto the bike making sure the fit is correct before tightening.

