TIGER 05> HUGGER

<u>Part # 076140</u> Fitting kit:

I Itting Mit.	
1 x Stainless steel bracket	CFK076140
1 x M6 x 35mm socket Allen bolt	CBOLM60030
2 x M6 x 16mm button Allen bolts	CBOLM60008
2 x M6 x 20mm button Allen bolt	CBOLM60009
5 x nylon washers	CWASM60004
1 x M6 large washer	CWASM60008
2 x M6 Nyloc nuts	CNUTM60003
5 x M6 s/steel washers	CWASM60001

Please note: The Pyramid tiger Hugger is not suitable for off road use.

Fitting instructions:

In the first instance, mount the Hugger without fully tightening the fasteners and apply Loctite to all fasteners except the Nyloc nuts.

Remove the chain guard.

Unbolt the brake hose clip from the swing arm (do not remove the clip from the hose).

Secure the bracket at the rear chain guard mount with the two holes up and inboard. Use an M6 x 20mm bolt with steel washer. Place a nylon washer between the bracket and the swing arm.

Position the Hugger and secure to the bracket using the two M6 x 16mm bolts with steel and nylon washers – and the Nyloc nuts.

Secure at the forward chain guard mounts using M6 x 30mm bolt with steel and nylon washers and larger steel washer between the Hugger and the chain slipper.

Secure under the hose clip fixing using the M6 x 20mm bolt with s/steel washer, and a nylon washer between the hose clip and the Hugger.

Finally check Hugger alignment and secure all fasteners.

Please note: check hugger alignment and fasteners periodically.