

076800 Triumph Tiger 800 Hugger Instructions (all model variants)

Kit Includes:

4X M6 x 20mm Flanged Button Head Bolts	CBOLM60009
4X 13mm Grommet	CGROM60001
4X M6 Spacers	CSPAM60006

- Remove the original chainguard.
- Remove the exhaust can and both the brake hose mountings.
- **Fit the grommets & spacers** to the 4 holes in the Hugger - **fitting the grommets first aids fitting.**
- Slide the Hugger over the tyre from the rear. Attach the front fixing point on the exhaust can side with the brake hose clip on top of the grommet. Now finger tighten only (**See Fig 1**).
- Fit the rear mounting point on the exhaust can side with the brake hose clip on top of the Grommet. Again, finger tighten only (**See Fig 2**).
- Now fit both mounting points on the chainguard side and tighten all mounting points fully.
- Finally re-fit the exhaust can.

Please check all fasteners and alignment of the Hugger periodically.

When riding two up, off-road and/or on rough surfaces, we recommend the adjustment of the suspension settings to compensate for added weight.

The battery box can collide with the hugger when the stock suspension setting is too low.

Please refer to your owner's manual or consult Triumph for more information on these adjustments.

