



08023 **3M** Ventureshield Application Instructions

Kit Includes:

1X **3M** Ventureshield

1X **3M** Squeegee

The tough properties of **3M VentureShield** Paint Protection Film means that it will protect the most vulnerable painted surfaces of your vehicle from damage caused by stone chips, environmental elements, bugs, scratches and minor abrasions. All Pyramid Plastics accessories + Motorbike headlights, tanks and even helmets will benefit from 3M VentureShield Paint Protection Film.

The following are instructions for applying 3M Ventureshield.

- Be sure to work indoors on a clean surface.
- Thoroughly clean the product you are applying the Ventureshield to. Making sure there is no dust or dirt present is important for getting the best bond between the adhesive and product.
- You will need a water solution (relative in volume to the area you protecting) mixed with 4-6 drops of washing up liquid or soap.
- With a soft sponge/cloth, apply the water solution to the designated area of the product. It is important to cover the whole area you plan to apply the Ventureshield to, this makes it easier to position on the product. It is also advised to apply the water solution to your hands to avoid fingerprints in the VentureShield.
- Remove the backing paper and be sure to avoid the adhesive side of the Ventureshield. The more contact you make with the adhesive, the less effective it will be after application.
- Lay the Ventureshield onto the product and move into position. The water allows enough movement for optimum placement on the product.
- When you have positioned the Ventureshield, carefully wipe away any excess water on top of and around the Ventureshield.
- Now use the Squeegee to remove the water from underneath the Ventureshield.
- Lastly, leave the Ventureshield for 10 minutes to cure.

Got questions?

sales@pyramid-plastics.co.uk

+44 (0)1427 677990

www.pyramid-plastics.co.uk

Follow us on social media and feel free to leave us a review!

