

PYRAMID

08124 Yamaha XT1200Z Super Ténéré Ductail Fitting Instructions

Kit Includes:

1X	C08124	Moulding
2X	CRIV0003	Black Plastic Push Rivets

- Two 4mm holes need to be drilled on both sides of the OEM guard & Pyramid Ductail - see diagram below.
- Clean the OEM guard for maximum adhesion. Remove the backing paper from the pre-fitted tape and fit onto the OEM guard.
- Be sure to line up the mounting points when fitting, use the 2X Black Plastic Push Rivets to attach the Pyramid Ductail at these two mounting points.

Got questions?

sales@pyramid-plastics.co.uk

+44 (0)1427 677990

www.pyramid-plastics.co.uk



Follow us on social media and feel free to leave us a review!



PYRAMID

08124 Yamaha XT1200Z Super Ténéré Ductail Fitting Instructions

Kit Includes:

1X	C08124	Moulding
2X	CRIV0003	Black Plastic Push Rivets

- Two 4mm holes need to be drilled on both sides of the OEM guard & Pyramid Ductail - see diagram below.
- Clean the OEM guard for maximum adhesion. Remove the backing paper from the pre-fitted tape and fit onto the OEM guard.
- Be sure to line up the mounting points when fitting, use the 2X Black Plastic Push Rivets to attach the Pyramid Ductail at these two mounting points.

Got questions?

sales@pyramid-plastics.co.uk

+44 (0)1427 677990

www.pyramid-plastics.co.uk



Follow us on social media and feel free to leave us a review!

