

PYRAMID

08452 W800 Cafe Racer Nose Fairing Fitting Instructions

Kit Includes:

X2	Mounting Brackets	CFK - 08452
X1	Fairing	C - 08452
X1	Screen	
X4	M5 X 20mm Bolt	CBOL - 0115
X7	M5 X 16mm Bolt	
X2	M8 X 60mm Bolt	CBOL - 0306
X4	10mm Spacer	
X11	M5 Well Nuts	CNUT - 0156
X11	M5 Black Plastic Washer	CWAS - 0100
X2	M8 Nyloc Nut	CNUT - 0301
X4	M8 Flat Spring Steel Washer	CWAS - 0300
X1	Screen Edge Trim	C - 08021
X1	Headlight Aperture Trim	

- Attach the mounting brackets supplied as shown in the image below. Use two 10mm spacers on each side of the headlight in conjunction with the M8 X 60mm bolts, M8 nyloc nuts & M8 flat steel washers.
- Attach the screen trim and headlight aperture trim - fit the screen to the brackets using the remaining fittings supplied.

Be sure to check all fixings periodically.



Brackets fitted on the bike

W800

Any questions?
sales@pyramid-plastics.co.uk
+44 (0)1427 677990
www.pyramid-plastics.co.uk

Follow us on social media and feel free to leave us a review!

