



085201 Yamaha MT-07 & XSR700 Spray Guard

Kit Includes:

1X Fibreglass Guard	C085201
1X M6 Steel Washer	CWASM60001
1X Spindle Spacer	CSPAM60015
2X Spindle Bolts - one at 160mm - one at 190mm	CBOLM60028/CBOLM60029
1X M6 Standard Nut & M6X30 Hexagonal Threaded Spacer	CNUTM60005/CSPAM60016

Note: You are advised never to attach additional items anywhere on this Spray Guard such as mounting plates, indicators, lights, licence plates, crash protectors, etc as this will invalidate the warranty.

This Spray Guard is simple to fit using two allen keys.

The image shows the Spray Guard in the correct position.
This Spray Guard will rotate on the wheel spindle bracket to alternative positions.

Please **do not** fit the Spray Guard at any alternative positions as it is not designed to be fitted in this way. **Fit only in the position shown here.**

- To assemble, pass the two long allen bolts through the hollow wheel spindle and fully tighten with the Spray Guard fitted on riders right hand side of the bike. Use two allen keys of at least 125mm in length.
- Check all positions for clearance before & after your first ride.
Bear in mind that there will be some movement of the Spray Guard head whilst riding.
- It is important to periodically check the mounting point for this Spray Guard.
Any loosening can cause serious damage to the Fibreglass Guard.
- Finally torque the wheel nut to the correct value of **105Nm**.



sales@pyramid-plastics.co.uk
+44 (0)1427 677990
www.pyramid-plastics.co.uk