

PYRAMID

085400 BMW F700GS & F800GS Spray Guard Fitting Instructions

- Remove rear wheel spindle completely.
- Replace standard BMW chain adjuster block with the Spray Guard assembly (left side of bike).
- Ensure steel spacer (Fig 1) is in place on the rear face of the Spray Guard mounting bracket during assembly.
- Re-assemble ensuring correct chain adjustments.
- Tighten the spindle nut to the correct torque setting of 100Nm.

Fig 1



sales@pyramid-plastics.co.uk
+44 (0)1427 677990
www.pyramid-plastics.co.uk

PYRAMID

085400 BMW F700GS & F800GS Spray Guard Fitting Instructions

- Remove rear wheel spindle completely.
- Replace standard BMW chain adjuster block with the Spray Guard assembly (left side of bike).
- Ensure steel spacer (Fig 1) is in place on the rear face of the Spray Guard mounting bracket during assembly.
- Re-assemble ensuring correct chain adjustments.
- Tighten the spindle nut to the correct torque setting of 100Nm.

Fig 1



sales@pyramid-plastics.co.uk
+44 (0)1427 677990
www.pyramid-plastics.co.uk