

SV1000 03-09 Fairings Lower Part # 20675

Fitting kit:

- 1 x Left hand bracket - CFK20675
- 1 x Right hand bracket - CFK20675
- 2 x M6 Aluminium Rivet Nut (pre-fitted by Pyramid) - CPNUTM60001
- 4 x M4 x 16mm Flange headed bolt - CBOLM40003
- 4 x M4 Rubber nut - CNUTM40001
- 4 x M5 Plastic washers - CWASM50001
- 2 x M6 Lug nut - CNUTM60007
- 2 x M6 x 16mm Flange headed bolt - CBOLM60008
- 2 x M6 Plastic washers - CWASM60003
- 6 x Steel countersunk washers - CWASM60006
- 6 x Rubber washers - CWASM60007
- 3 x M6 x 35mm countersunk bolt - CBOLM60017
- 1 x M6 x 50mm countersunk bolt - CBOLM60018
- 2 x M6 x 25mm countersunk bolt - CBOLM60015
- 1 x Large white spacer (left hand side) - CSPAM100002
- 1 x Small spacer (right hand side) - CSPAM60018
- 2 x Black spacers - CSPAM60003

Fitting instructions:

1. Remove original belly pan and brackets.
2. Fit new brackets as shown in pictures below.
3. Remove metal guard from radiator.
4. Undo the two upper fairing fixing points and remove rubber grommet.
5. Insert 4 x M4 rubber nuts into front of center panel.
6. Insert 2 x M6 lug nuts into bottom of center panel.
7. Fit center panel to left side of lowers using 2 x M4 bolts with M5 plastic washers and 1 x M6 flange headed bolt with M6 plastic washer.
8. Offer left hand panel up to the bike with top mounting lug behind nose fairing mounting point and use M6 x 35mm counter sunk bolt with a recessed steel washer and rubber washer. (Don't fully tighten).
9. Fit radiator mounting using M6 x 45mm counter sunk bolt with steel recessed washer with rubber washer. Large white spacer with black spacer should be placed on the bolt between fairing and radiator. (Don't fully tighten).
10. Fit bottom mounting using M6 x 25mm counter sunk bolt with steel recessed washer and rubber washer. (Don't fully tighten)
11. Repeat process on right side of bike using small white spacer and black spacer for the radiator mounting point with M6 x 35mm counter sunk bolt.
12. Join to mid panel using remaining M4 bolts, M5 washers, M6 bolt and washer.
13. Tighten **all** mounting points fully.
14. Check **all** fixings periodically.



right hand bracket



left hand bracket

A youtube fitting video is available at [youtube.com/pyramidplastix](https://www.youtube.com/pyramidplastix)