

Kit includes:

2X	CFK207025	GSF1250 Lower Brackets (A+B)
2X	CBOLM60011	M6 x 25mm Flanged Button Head
2X	CBOLM60008	M6 x 16mm Flanged Button Head
2 X	CBOLM60012	M6 x 30mm Flanged Button Head
6X	CGROM60001	13mm Open Rubber Grommet
6X	CSPAM60004	8mm Steel Collar
2X	CWASM60007	Rubber Washer
2 X	CSPAM60010	White Plastic Spacer
2X	CSPAM60003	Black Plastic Washer
2 X	CWASM60001	Flat Steel Washer
2X	CNUTM60003	Nyloc Nut
4X	CFOA0003	30mm Lenath Foam

- 1. On both sides of the bike remove the rear mounting of the nose fairing, the upper mounting of the radiator side. Also remove the radiator side plates. Fig 1
- 2. Fit the brackets for the rear belly pan mountings as shown in Fig 2 and Fig 3.
- 3. Feed the upper mounting moulding of the right hand side panel under the rear mounting of the nose fairing and loosely fasten with the original bolt.
- 4. Loosely fasten the radiator mounting using an M6 x 20mm flange headed bolt with an M6 x 10mm white nylon spacer in between the panel and the radiator.
- 5. Repeat the process for the left hand panel.
- 6. Place a protective cover under the bike to avoid the belly pan being scratched during fitting.
- 7. Insert the rubber grommets into the rear mounting holes in the belly pan and insert the steel collars into the grommets. (Note: the foam pads supplied with the fitting kit are used to create a gasket between the fairing panels and the belly pan – see Fig 4).
- 8. Offer the belly pan up to the brackets and loosely fasten to both rear brackets using M6 x 16mm flange headed bolts.
- 9. Now feed the front mountings of the belly pan under the side panels until the mountings of the belly pan and side panels match up.
- 10. Secure the belly pan to the side panels using the remaining M6 x 30mm bolts attached with the following rubber washer, black plastic washer, flat steel washer and nyloc nut (10 full allen key rotations to fully secure).
- 11. Check the fit and tighten all of the mountings fully.
- 12. Remember to check all fixings periodically.







Any questions? sales@pyramid-plastics.co.uk +44 (0)1427 677990 www.pyramid-plastics.co.uk



