

CONTENTS

6 x Mounting bracket	CFK21056
4 x M6 x 25mm countersunk bolt	CBOLM60015
4 x M6 aluminum washer	CWASM60006
2 x M6 nyloc nut	CNUTM60003
4 x M4 x 16 bolt, nut, washer	CBOLM40003/CNUTM40002/CWASM40001
2 x lugnut (fitted to bracket)	CNUTM60007
4 x 13mm grommet	CGROM60001
4 x M6 x 6mm spacer	CSPAM60006

fitting instructions

Remove rear two sump bolts on left hand side of bike, then offer up triangle shaped bracket RL (see pic 1), the bracket will only fit in one place. Replace sump bolts and tighten.

Repeat procedure on other side of bike using bracket RR (pic 1).

Assemble front brackets using the M4 bolts washers and nuts (pic 2, pic 3), then remove left side front two sump bolts and engine casing bolt directly above, fit bracket FL, replace bolts and tighten.

Repeat the procedure on the other side using bracket FR.

When all brackets are in place, offer up the belly pan and line up holes with bracket holes, attach front of belly pan using M6 bolts, aluminium & rubber washers into lugnuts fitted to brackets loosely, then attach to rear brackets using M6 bolts washers and nyloc nuts loosely, check fit of belly pan then tighten all bolts.

PIC 1



PIC 2



PIC 3

