

Super Tenere XT1200Z 2010 > Frame Infill Panel Part # 22125

Contents

2 x M8 x 40mm dome head Allen bolt – CBOLM80012

1 x small cable tie – CAB0200

Fitting Instructions

- Remove the pillion foot peg from the right hand side of the bike
- Fit the panel to the bike with the pillion peg over the top of the panel using the M8 x 40mm bolts provided. (do not tighten fully at this stage)
- Feed the cable tie through the slot in the rear of the panel and then through the small hole in the frame.
- Fully tighten the pillion peg fixings – torque spec 20 ft lb. (USA) / 27.1163590 Nm (UK/Europe) - and pull the cable tie until it holds the panel firmly at the back.
- **Check all fixings periodically.**

Super Tenere XT1200Z 2010 > Frame Infill Panel Part # 22125

Contents

2 x M8 x 40mm dome head Allen bolt – CBOLM80012

1 x small cable tie – CAB0200

Fitting Instructions

- Remove the pillion foot peg from the right hand side of the bike
- Fit the panel to the bike with the pillion peg over the top of the panel using the M8 x 40mm bolts provided. (do not tighten fully at this stage)
- Feed the cable tie through the slot in the rear of the panel and then through the small hole in the frame.
- Fully tighten the pillion peg fixings – torque spec 20 ft lb. (USA) / 27.1163590 Nm (UK/Europe) - and pull the cable tie until it holds the panel firmly at the back.
- **Check all fixings periodically.**